



GASTROPARTS

HORO

- [EN]** Equipment
- [DE]** Geräte
- [ES]** Aparatos
- [FR]** Équipement
- [IT]** Attrezzature
- [PL]** Urządzenia
- [RU]** Оборудование

✉ gastroparts@gastroparts.com

☎ +48 56 657 00 66

📘 fb.com/gastroparts.global

GASTROPARTS.COM





switches and momentary switches

cam switches

on/off



1

Part No.	300021	Ref. No.	N/A
description	cam switch 4 operating positions 4NO sequence 0-1-0-1 16A shaft ø 6x4.6mm shaft L 23mm connection screw ceramic		



1

Part No.	970453	Ref. No.	70 38 Friteusenkorb 38x38 cm
description	fryer basket L1 370mm W1 370mm H1 110mm L2 585mm H2 200mm		

baskets

fryer baskets

HORO



1

Part No.	970452	Ref. No.	Fritierkorb 37x17
description	fryer basket L1 350mm W1 170mm H1 150mm SS		

GASTROPARTS.COM

