








GASTROPARTS

switches

PRZEŁĄCZNIKI

-  www.gastroparts.com
-  gastroparts@gastroparts.com
-  tel. +48 56 657 00 68
-  [/gastroparts.global](https://www.facebook.com/gastroparts.global)
-  [/gastroparts.global](https://www.instagram.com/gastroparts.global)

Switches

push switches/momentary push switches
mounting \varnothing 22.3mm



fig.	part no.	description	contacts	schematic
1	346316	switch	2NO 16A/250V	F
1	345038	momentary switch	2NO 16A/250V	G
2	345212	switch	2NO 16A/250V	F
3	345037	switch	2NO 16A/250V	F
4	346002	momentary switch	2NO 16A/250V	G



fig.	part no.	description	contacts	schematic
1	345160	switch, lighted	2NO 16A/250V	H
1	346121	momentary switch, lighted	2NO 16A/250V	I
1	346003	momentary switch + lamp	1NO 16A/250V	D
2	345161	switch, lighted	2NO 16A/250V	H
2	347095	momentary switch, lighted	2NO 16A/250V	I
2	346936	momentary switch + lamp	1NO 16A/250V	D
3	345162	switch, lighted	2NO 16A/250V	H
3	345962	momentary switch + lamp	1NO 16A/250V	D
4	300161	switch, lighted	2NO 16A/250V	H
4	300169	momentary switch + lamp	1NO 16A/250V	D



no.	part no.	description	contacts	schematic
1	345152	momentary switch	2NO 16A/250V	G
2	345151	switch, lighted	2NO 16A/250V	H
3	345961	momentary switch + lamp	1NO 16A/250V	D



fig.	part no.	description	contacts	schematic
1	346496	switch	2NO 16A/250V	F
2	346039	switch	2NO 16A/250V	F



fig.	part no.	description	contacts	schematic
1	346044	momentary switch	2NO 16A/250V	G
2	346040	momentary switch	2NO 16A/250V	G



fig.	part no.	description	contacts	schematic
1	346505	switch, lighted	2NO 16A/250V	H
2	346504	switch, lighted	2NO 16A/250V	H
3	346497	switch, lighted	2NO 16A/250V	H




fig.	part no.	description	contacts	schematic
1	359202	indicator light	250V	Z
2	359203	indicator light	250V	Z
3	359204	indicator light	250V	Z
4	345039	protective cover	-	

mounting 19x13mm



fig.	part no.	description	connection	contacts	schematic
1	347079	switch, lighted	F 6.3mm	2NO 16A/250V	H
2	347106	momentary switch	F 6.3mm	1NO.16A/250V	A
2	347105	switch	F 6.3mm	1NO.16A/250V	K
3	347292	switch, lighted	F 6.3mm	2NO 16A/250V	H



SWITCHES - UNIVERSAL PARTS



fig.	part no.	description	connection	contacts	schematic
1	301190	switch	F 4.8mm	2NO 16A/250V	F
2	301191	momentary switch	F 6.3mm	2NO. 16A/250V	G
3	346117	button	-	-	-



fig.	part no.	description	contacts	schematic
1	346022	switch	2NO 16A/250V	F
2	346417	momentary switch	2NO 16A/250V	G
3	346128	momentary switch	2NO 16A/250V	G
4	346129	momentary switch + lamp	1NO 16A/250V	D



fig.	part no.	description	connection	contacts	schematic
1	346116	switch	F 6.3mm	2NO 16A/250V	F
2	346114	switch	F 6.3mm	2NO 16A/250V	F
3	346115	momentary switch	F 6.3mm	1NO. 16A/250V	A



fig.	part no.	description	contacts	schematic
1	346060	switch	2NO 16A/250V	F
2	346051	momentary switch	2NO 16A/250V	G
3	346050	momentary switch	2NO 16A/250V	G

mounting 27.2x22.2mm



fig.	part no.	description	contacts	schematic
1	345033	switch, lighted	2NO 16A/250V	H
1	345090	momentary switch, lighted	2NO 16A/250V	I
2	345035	switch, lighted	2NO 16A/250V	H
2	346598	switch + lamp	1NO 16A/250V	M1



fig.	part no.	description	contacts	schematic
1	359199	indicator light	230V	Z
2	359209	indicator light	230V	Z
3	359911	indicator light	230V	Z


mounting 30x22mm



fig.	part no.	description	contacts	schematic
1	301040	switch, lighted	2NO 16A/250V	H
1	301042	momentary switch, lighted	2NO 16A/250V	I
2	301041	switch, lighted	2NO 16A/250V	H
2	301043	momentary switch, lighted	2NO 16A/250V	I



no.	part no.	description	contacts	schematic
1	345094	switch + lamp	2NO 16A/250V	L
2	345098	momentary switch + lamp	2NO 16A/250V	J



rocker switches/ momentary rocker switches mounting 19x13mm



fig.	part no.	description	contacts	schematic
1	301047	switch, lighted	2NO 16A/250V	H
1	301050	momentary switch, lighted	2NO 16A/250V	I
2	301048	switch, lighted	2NO 16A/250V	H
2	301051	momentary switch, lighted	2NO 16A/250V	I
3	301049	switch + lamp	2NO 16A/250V	L
3	301052	momentary switch + lamp	2NO 16A/250V	J
4	346536	switch	2NO 16A/250V	F
4	345963	momentary switch	2NO 16A/250V	G



fig.	part no.	description	connection	contacts	schematic
1	301067	switch, lighted	F 4.8mm	2NO 10A/250V	H1
1	346450	switch, lighted	F 2.8mm	2NO 10A/250V	H1
2	301068	switch, lighted	F 4.8mm	2NO 10A/250V	H1
3	301069	switch, lighted	F 4.8mm	2NO 10A/250V	H1
4	301066	switch	F 4.8mm	2NO 10A/250V	F1

mounting 19x22mm



fig.	part no.	description	contacts	schematic
1	345235	switch, lighted	2NO 16A/250V	H
1	345237	momentary switch, lighted	2NO 16A/250V	I
2	345236	switch, lighted	2NO 16A/250V	H
2	345238	momentary switch, lighted	2NO 16A/250V	I
3	346041	switch, lighted	2NO 16A/250V	H
3	347024	momentary switch + lamp	1NO 16A/250V	D
4	346048	momentary switch	1NO 16A/250V	A



fig.	part no.	description	contacts	schematic
1	346134	switch, lighted	2NO 10A/250V	H1
2	346133	switch, lighted	2NO 10A/250V	H1
3	346550	switch, lighted	2NO 10A/250V	H1
4	346549	switch	2NO 10A/250V	F1

mounting 26.5x25.6mm






fig.	part no.	description	contacts	schematic
1	301082	switch, lighted	2NO 16A/250V	H
2	301083	switch, lighted	2NO 16A/250V	H
3	301084	switch, lighted	2NO 16A/250V	H



fig.	part no.	description	contacts	schematic
1	345013	switch, lighted	2NO 16A/250V	H1
2	345277	switch, lighted	2NO 16A/250V	H1
3	345278	switch, lighted	2NO 16A/250V	H1
4	301245	switch, lighted	2NO 16A/250V	H1



fig.	part no.	description	contacts	schematic
1	301086	switch	2NO 16A/250V	F
2	346052	switch, lighted	2CO 16A/250V	S1



SWITCHES - UNIVERSAL PARTS



fig.	part no.	description	contacts	schematic
1	345282	switch, lighted	2CO 16A/250V	S1
1	347116	momentary switch, lighted	2CO 16A/250V	V1
2	345281	switch, lighted	2CO 16A/250V	S1
2	347117	momentary switch, lighted	2CO 16A/250V	V1
3	345280	switch, lighted	2CO 16A/250V	S1
3	347118	momentary switch, lighted	2CO 16A/250V	V1
4	347115	switch, lighted	2CO 16A/250V	S1
4	347119	momentary switch, lighted	2CO 16A/250V	V1

mounting 30x11mm



fig.	part no.	description	contacts	schematic
1	301053	switch, lighted	1NO 16A/250V	O1
2	301010	switch, lighted	1NO 16A/250V	O1
3	301011	switch, lighted	1NO 16A/250V	O1
4	301012	switch, lighted	1NO 16A/250V	O1
4	345381	switch, lighted	1NO 16A/24V	O1



fig.	part no.	description	contacts	schematic
1	347120	switch, lighted	2NO 16A/250V	H1
1	347123	switch, lighted	2CO 16A/250V	S1
1	347127	momentary switch, lighted	2CO 16A/250V	V1
2	347121	switch, lighted	2NO 16A/250V	H1
2	347124	switch, lighted	2CO 16A/250V	S1
2	347128	momentary switch, lighted	2CO 16A/250V	V1
3	345003	switch, lighted	2NO 16A/250V	H1
3	347125	switch, lighted	2CO 16A/250V	S1
3	347129	momentary switch, lighted	2CO 16A/250V	V1
4	347122	switch, lighted	2NO 16A/250V	H1
4	347126	switch, lighted	2CO 16A/250V	S1
4	345191	momentary switch, lighted	2NO 16A/250V	V1




fig.	part no.	description	contacts	schematic
1	301013	switch	1CO 16A/250V	P1
2	301014	momentary switch	1NO 16A/250V	A1
3	345575	switch	1NO-1NO 16A/250V	R1



fig.	part no.	description	contacts	schematic
1	301039	switch lighted	1NO 16A/250V	O1
2	301037	switch lighted	1NO 16A/250V	O1
3	301038	switch lighted	1NO 16A/250V	O1
4	301035	protective cover	-	-



fig.	part no.	description	contacts	schematic
1	345002	switch	2CO 16A/250V	P2
1	347130	momentary switch	2CO 16A/250V	U1
2	347131	switch	2CO 16A/250V	P2
3	345190	switch	2CO 16A/250V	P2



mounting 30x22mm



fig.	part no.	description	contacts	schematic
1	301009	switch, lighted	2NO 16A/250V	H1
1	301085	momentary switch, lighted	2NO 16A/250V	I1
2	301001	switch, lighted	2NO 16A/250V	H1
2	301020	momentary switch, lighted	2NO 16A/250V	I1
2	301091	switch, lighted	2NO 10A/400V	H1
3	301002	switch, lighted	2NO 16A/250V	H1
3	301018	momentary switch, lighted	2NO 16A/250V	I1
3	345512	switch, lighted	2NO 10A/400V	H1
3	301135	momentary switch, lighted	2NO 16A/24V	I1
4	301003	switch, lighted	2NO 16A/250V	H1
4	301019	momentary switch, lighted	2NO 16A/250V	I1
4	301137	switch, lighted	2CO 10A/400V	H1



fig.	part no.	description	contacts	schematic
1	301140	switch	2CO 16A/250V	P2
2	301188	switch	2NO-2NO 16A/250V	R2
2	346852	switch/momentary switch	2NO-2NO 16A/250V	W2
3	345356	momentary switch	1CO 16A/250V	U



fig.	part no.	description	contacts	schematic
1	346081	switch	2NO 16A/250V	K2
2	346082	switch	2NO 16A/250V	K2
3	346083	switch	2NO 16A/250V	K2
4	301717	momentary switch	1NO 16A/250V	A1




fig.	part no.	description	contacts	schematic
1	301078	momentary switch	2NO 16A/250V	A2
1	346066	switch	2NO 16A/250V	K2
1	346978	momentary switch	2CO 16A/250V	U1
2	301004	switch	2CO 16A/250V	P2
3	301101	switch	2CO 16A/250V	P2
4	346361	switch	2CO 16A/250V	P2



fig.	part no.	description	contacts	schematic
1	301081	switch, lighted	2CO 16A/250V	S1
2	301015	switch, lighted	2CO 16A/250V	S1
3	301016	switch, lighted	2CO 16A/250V	S1
4	301017	switch, lighted	2CO 16A/250V	S1
4	301137	switch, lighted	2CO 10A/400V	S1



fig.	part no.	description	contacts	schematic
1	346377	switch	2NO 16A/250V	K2
2	301098	momentary switch	2NO 16A/250V	A2



SWITCHES - UNIVERSAL PARTS



fig.	part no.	description	contacts	schematic
1	301060	switch, lighted	2NO 16A/250V	H1
2	301061	switch, lighted	2NO 16A/250V	H1
2	346937	momentary switch, lighted	2CO 16A/250V	V1
3	301062	switch, lighted	2NO 16A/250V	H1



fig.	part no.	description	contacts	schematic
1	346164	switch, lighted	2NO 16A/250V	H1
2	346981	switch, lighted	2NO 16A/250V	H1
3	347113	switch, lighted	2NO 16A/250V	H1
4	347114	switch, lighted	2NO 16A/250V	H1



fig.	part no.	description	contacts	schematic
1	346899	switch, lighted	2NO 16A/250V	H1
2	345645	switch, lighted	2NO 16A/250V	H1
3	345641	switch, lighted	2NO 16A/250V	H1
4	346896	switch	2NO 16A/250V	K2



fig.	part no.	description	contacts	schematic
1	345056	switch, lighted	2NO 16A/250V	H1
2	347112	switch, lighted	2NO 16A/250V	H1
3	346368	momentary switch	2CO 16A/250V	U1



fig.	part no.	description	contacts	schematic
1	345188	switch, lighted	2NO 16A/250V	H1
2	346046	switch, lighted	2NO 16A/250V	H1
3	346049	switch, lighted	2NO 16A/250V	H1
4	346047	switch, lighted	2NO 16A/250V	H1



fig.	part no.	description	contacts	schematic
1	301030	switch, lighted	2x1NO 16A/250V	2xO1
2	301031	switch, lighted	2x1NO 16A/250V	2xO1
3	301029	switch, lighted	2x1NO 16A/250V	2xO1







fig.	part no.	description	contacts	schematic
1	345599	switch, lighted	2x1NO 16A/250V	2xO1
2	345647	switch, lighted	2x1NO 16A/250V	2xO1



fig.	part no.	description	contacts	schematic
1	346108	switch, lighted	2NO 16A/250V	H1
2	346110	switch, lighted	2NO 16A/250V	H1
3	346109	switch, lighted	2NO 16A/250V	H1
4	346111	switch, lighted	2NO 16A/250V	H1



no.	part no.	description	contacts	schematic
1	301080	switch	1NO/1CO 16A/250V	K1 + P1



UNIVERSAL PARTS



2-hole mounting



fig.	part no.	description	contacts	schematic
1	301032	switch, lighted + lamp 230V	1NO 16A/250V	O1 + Z
2	301033	switch, lighted + lamp 230V	1NO 16A/250V	O1 + Z
3	301034	switch, lighted + lamp 230V	1NO 16A/250V	O1 + Z

no.	part no.	description	hole distance	contacts	schematic
1	346161	switch	50mm	3NO 10A/400V ON-OFF	K3



fig.	part no.	description	contacts	schematic
1	301036	protective cover	-	-
2	346474	dummy element	-	-



no.	part no.	description	hole distance	contacts	schematic
1	346149	switch	47mm	3NO 16A/250V ON-OFF	K3

mounting 36.5x22mm



fig.	part no.	description	contacts	schematic
1	346074	switch, lighted	2NO 12A/250V	H1
2	346036	switch, lighted	2NO 12A/250V	H1

series Domino-ST complete



fig.	part no.	description	contacts	suitable for
1	345142	switch	2 NO	Vibiemme Faema
2	346019	switch	2 NO	Elektra
3	346091	switch	2 NO	

toggle switches/ momentary toggle switches

mounting $\varnothing 6\text{mm}$






fig.	part no.	description	contacts	schematic
1	346519	switch	2NO 15A/250V ON-OFF	K2
2	346529	switch	2CO 15A/250V ON-ON	P2
2	346520	switch	2CO 15A/250V ON-OFF-ON	R2

series Domino-SQ complete

single



no.	part no.	description	contacts	suitable for
1	346502	switch	2 NO	Vibiemme



micro-switches

micro-switches universal




fig.	part no.	function	switch power	connection
1	345214	1CO	6A/250V	cable 500mm
2	345229	lever set	-	-
3	347006	1NO	10A/250V	cable 700mm




fig.	part no.	function	switch power	connection
1	346141	1NO	10A/250V	faston 2.8mm
2	346137	1CO	5A/250V	solder connection
3	347026	1CO	5A/250V	solder connection
4	347021	1CO	3A/250V	solder connection

micro-switches with lever



no.	part no.	L (mm)	function	switch power	connection (mm)
1	345256	26.5	1CO	16A/250V	faston 6.3
2	345257	31.5	1CO	16A/250V	faston 6.3
3	346456	36	1CO	0.1A/250V	faston 6.3
4	345255	36	1CO	16A/250V	faston 6.3
5	347010	36	1CO	16A/250V	faston 4.8
6	346969	50	1NO	16A/250V	faston 6.3
7	345742	56	1CO	16A/250V	faston 6.3
8	346872	58	1CO	0.1A/250V	faston 6.3
9	345773	60	1CO	16A/250V	faston 6.3
10	345254	66	1CO	16A/250V	faston 6.3
11	345345	69	1CO	16A/250V	faston 6.3
12	346072	71	1CO	6A/250V	faston 6.3
13	345107	100	1CO	16A/250V	faston 6.3

micro-switches with roller lever



no.	part no.	L (mm)	function	switch power	connection (mm)
1	345041	20.5	1CO	16A/250V	faston 6.3
2	345252	25	1CO	16A/250V	faston 6.3
3	345253	30	1CO	16A/250V	faston 6.3
4	345250	34.5	1CO	16A/250V	faston 6.3
5	345251	41	1CO	16A/250V	faston 6.3

micro-switches universal



fig.	part no.	function	switch power	connection
1	345042	1CO	16A/250V	faston 6.3mm
2	300158	1CO	8A/250V	cable 1500mm
3	345043	lever set	-	-

basic micro-switches



fig.	part no.	function	switch power	connection (mm)
1	345105	1CO	16A/250V	faston 6.3mm
2	346158	1CO	5A/250V	faston 4.8mm
3	346145	1CO	10A/250V	faston 4.8mm
4	347043	1NC	16A/250V	faston 4.8mm

micro-switches with non-standard levers



no.	part no.	function	connection (mm)	suitable for	equiv. no.
1	346152	1CO	faston 6.3	Mazzer	S00SMIA04

micro-switches with front fixing



fig.	part no.	fixing	function	switch power	connection (mm)
1	345032	M10x0.75mm	1CO	16A/250V	faston 6.3
2	345350	M12x0.75mm	1CO	16A/250V	faston 6.3



no.	part no.	fixing	function	switch power	connection (mm)
1	345104	M10x0.75mm roller plunger	1CO	16A/250V	faston 6.3

micro-switches with lever



no.	part no.	L (mm)	function	switch power
1	345268	38	1CO	16A/250V
2	345269	54	1CO	16A/250V
3	345125	63.5	1CO	16A/250V
4	345044	72	1CO	16A/250V
5	345270	133	1CO	16A/250V
6	345074	146.5	1CO	16A/250V
7	345271	152.5	1CO	16A/250V
8	346908	172	1CO	16A/250V

micro-switches with roller lever



no.	part no.	L (mm)	function	switch power
1	346874	25	1CO	16A/250V
2	347076	30	1CO	16A/250V
3	345266	34.5	1CO	16A/250V
4	345485	47	1CO	16A/250V
5	345045	50.5	1CO	16A/250V
6	345267	60	1CO	16A/250V

micro-switches non standard types



no.	part no.	function	switch power	suitable for	equiv. no.
1	345103	1CO	20A/400V	San Marco	

micro-switches, front fixing



fig.	part no.	fixing	function	switch power
1	345156	M10x1mm	1CO	16A/250V
2	345138	M12x1mm	1CO	16A/250V
3	345258	M12x1mm	1CO	16A/400V



fig.	part no.	fixing	function	switch power
1	345694	M12x1mm	1CO	16A/250V
2	345679	M12x1mm	1CO	16A/250V
3	347009	M12x1mm	1CO	20A/250V



fig.	part no.	fixing	function	switch power
1	346370	M12x1mm	1CO	16A/250V
2	347096	M12x1mm	1CO	16A/250V

Lamps

indicator lamps and housings built-in housings for lamp types A-C

mounting- \varnothing 10mm, plug type



fig.	part no.	colour	lamp	fig.	part no.	colour	lamp
1	359124	yellow	type A	3	359125	red	type A
2	359123	green	type B	4	359228	clear	type A

mounting- \varnothing 12mm, plug type



fig.	part no.	colour	lamp	fig.	part no.	colour	lamp
1	359260	yellow	type A	3	359261	red	type A
2	359262	green	type B	4	359280	clear	type A

mounting- \varnothing 12mm, plug type




fig.	part no.	colour	lamp	fig.	part no.	colour	lamp
1	359278	yellow	type A	4	359275	clear	type A
2	359277	green	type B	5	359792	blue	type C
3	359276	red	type A				



GASTROPARTS

GASTROPARTS Sp. J.
Klonowica 37
87-100 Toruń

www.gastroparts.com 

gastroparts@gastroparts.com 

tel. +48 56 657 00 68 

[/gastroparts.global](https://www.facebook.com/gastroparts.global) 

[/gastroparts.global](https://www.instagram.com/gastroparts.global) 