



GASTROPARTS

Ambach

[EN] Cooking

[DE] Kochtechnik

[ES] Cocción

[FR] Cuisson

[IT] Cottura

[PL] Obróbka termiczna

[RU] Термическая обработка

✉ gastroparts@gastroparts.com

☎ tel. +48 56 657 00 66

📘 fb.com/gastroparts.global

GASTROPARTS.COM



TABLE OF CONTENTS

Open tops (gas/electric)



page 4

Ovens (gas/electric)



page 9

Hot cupboards (electric)



page 12

Fry tops (gas/electric), multi bratt pans (electric)



page 13

Lava rock grills (gas)



page 15


TABLE OF CONTENTS

Pasta cookers (gas/electric)



page 16

Bains-marie (electric)



page 17

Fryers (gas/electric)




page 18

Tilting bratt pans (gas/electric)



page 21

Boiling pans (gas/electric)



page 28

A Open tops (gas)



Item	Order	Description	Model	OEM
1	103038	burner cover (B)	GHG/70	3018703054
2	104060	burner (B)		2016902026
3	103039	burner cover (C)		3018702019
4	104061	burner (C)		2016902017



Item	Order	Description	Model	OEM
1	100096	pilot burner	GR35/70/105	5024708974
2	101293	aluminium gasket	GRG70/105 (1-series)	5017302671
3	100091	pilot burner	GRG70/105 (2-series)	5024708680
4	100919	spring		5004708809



Item	Order	Description	Model	OEM
1	101069	gas tap	GHG/70	5018904111 5018904112
2	110350	knob		5022902024
3	102202	thermocouple, 320mm		5024102013
3	102204	thermocouple, 600mm		5024102012



Item	Order	Description	Model	OEM
1	101095	gas tap	GRG70/105 (1+2-series)	5018905405 5018905406
2	110351	knob		5022908973
3	102202	thermocouple, 320mm		5024102013
3	102204	thermocouple, 600mm		5024102012

no longer available



Item	Order	Description	Model	OEM
1	n.l.a.	ignition switches	GHG/70	5060902399
2	100715	electrode		5062602389
3	101014	ignition unit		5060402388



Item	Order	Description	Model	OEM
1	103040	burner cover (C)	HG40/80/120/160 HGE80/120/160 HGG80/120/160	5018705710
2	104062	burner base (C)		2016905411
3	104064	Venturi (C)		2000605350
4	104066	aeration sleeve		3028604319



Item	Order	Description	Model	OEM
1	103042	burner cover (C)	GR35/70/105 (1+2-series) GRG70/105 (1+2-series) GRE70 (1+2-series)	5018709571 5018708871
2	104067	burner (C)		5016909391 5016908861
3	103043	burner cover (D)		5018709572 5018708872
4	104068	burner (D)		5016909392 5016908863
5	105264	O-ring		5017308860



Item	Order	Description	Model	OEM
1	104381	burner cover (D)	HG40/80/120/160 HGE80/120/160 HGG80/120/160	5018705711
2	104382	burner base (D)		2016905412
3	104065	Venturi (D+E)		2000605351
4	104066	aeration sleeve		3028604319




Item	Order	Description	Model	OEM
1	103041	burner cover (E)		5018705859
2	104063	burner base (E)	HG40/80/120/160 HGE80/120/160	2016905418
3	104065	Venturi (D+E)	HGG80/120/160	2000605351
4	100066	aeration sleeve		3028604319




Item	Order	Description	Model	OEM
1	100087	pilot burner, M8x1		5024704318
2	101293	aluminium gasket	HG40/80/120/160	5017302671
3	101927	elbow connector/input	HGE80/120/160	5051204360
4	101367	elbow connector/output	HGG80/120/160	5006304316
5	101369	jet holder		5051304317




Item	Order	Description	Model	OEM
1	101095	gas tap		5018905405 5018905406
2	110051	knob	HG40/80/120/160 HGE80/120/160	5022904344
3	102202	thermocouple, 320mm	HGG80/120/160	5024102013
3	102204	thermocouple, 600mm		5024102012




Item	Order	Description	Model	OEM
1	104383	burner cover (C)		5018714245
2	104384	burner head (C)		5016914265
3	104385	gasket	GH40/80/120 GHE80/120	5017314079
4	104386	holder housing	GHG80/120 GH45/90	5006314268
5	104387	elbow		5050120709
6	104388	Venturi (C)		5016914238




Item	Order	Description	Model	OEM
1	104389	burner cover (E)		5018714247
2	104390	burner head (E)		5016914267
3	104385	gasket	GH40/80/120 GHE80/120	5017314079
4	104386	holder housing	GHG80/120 GH45/90	5006314268
5	104387	elbow		5050120709
6	104391	Venturi (E)		5016914240




Item	Order	Description	Model	OEM
1	100091	pilot burner	GH40/80/120	5024708680
2	101945	pilot burner holder	GHE80/120	3006314269
3	100919	pilot burner spring	GHG80/120 GH45/90	5004708809
4	520120	clip		5028510569



Item	Order	Description	Model	OEM
1	101951	gas tap		5018914348
2	111570	knob	GH40/80/120 GHE80/120	5022908810
3	102251	thermocouple, 750mm	GHG80/120	5024114591
4	101295	thermocouple sleeve		5007403711




Item	Order	Description	Model	OEM
1	101950	gas tap		3018916600
2	111575	knob	GH45/90	5022914032
3	111576	symbol		5022914331
4	102251	thermocouple		5024114591



Item	Order	Description	Model	OEM
1	210133	top grate	GHG_	5010101970
2	210134	top grate	GRG_	5010108830 5010108970
3	210106	top grate	HGG_	5010104350 5010110315



Item	Order	Description	Model	OEM
1	104149	burner, 430mm	ZGG	5016907865
2	104393	burner, 570mm		5016907623
3	104392	ignition bridge, 140mm		5020307488
4	104124	ignition bridge, 230mm		5020307627



Item	Order	Description	Model	OEM
1	210008	spider	GHG_, GRG_	5010108996
2	210007	spider	HGG	5010104372



Item	Order	Description	Model	OEM
1	101095	gas tap	ZGG	5018905405
2	110051	knob		5022904344
3	102034	thermocouple, 450mm		5024102344

Open tops - range cookers (gas)



Item	Order	Description	Model	OEM
1	104149	burner	GZE/70	5016907865
2	104392	ignition bridge		5020307488
3	n.l.a.	gas tap EGA		5018902393
4	101640	gas tap PEL		5018902393



Item	Order	Description	Model	OEM
1	100046	pilot burner	ZGG	5024703475
2	100706	electrode		5062507632
3	100003	piezoelectric igniter		5060403707



Item	Order	Description	Model	OEM
1	101640	gas tap/PEL	GZE/70	5018902393
2	110350	knob		5022902024
3	102034	thermocouple, 450mm		5024103294



Item	Order	Description	Model	OEM
1	100079	pilot burner	ZGG	5024706878
2	100701	electrode		5062606677
3	100003	piezoelectric igniter		5060403707



Item	Order	Description	Model	OEM
1	100046	pilot burner	GZE/70	5024703475
2	100706	electrode		5062507632
3	100003	piezoelectric igniter		5060403707


Open tops (solid top)



Item	Order	Description	Model	OEM
1	104148	burner	GK70	5016907861
2	101089	gas tap		5018909180
3	110394	knob		5022908981




Item	Order	Description	Model	OEM
1	104148	burner	GPG	5016907861
2	101952	gas tap		5018903683
3	111571	knob		5022907196
4	110066	knob screw		3009600005



Item	Order	Description	Model	OEM
1	102034	thermocouple, 600mm	GK70 GPG	5024102394
2	100972	pilot burner		3524707258
3	100701	electrode		5062606677
4	100003	piezoelectric igniter		5060403707
5	100019	ignition cable		5061003550



Item	Order	Description	Model	OEM
1	104148	burner	GPS80	3516911678
2	101189	gas tap		5018909180
3	111570	knob		5022908810




Item	Order	Description	Model	OEM
1	102034	thermocouple, 600mm	GPS80	5024107489
2	100972	pilot burner		3524707258
3	100701	electrode		5062606677
4	100009	piezoelectric igniter		5060408640



Item	Order	Description	Model	OEM
1	104395	burner	GP45	5016914204
2	104396	burner	GP90	5016914277
3	102040	thermocouple, 500mm	GP45/90	5024110057



Item	Order	Description	Model	OEM
1	101950	gas tap	GP45 GP90	3018916600
2	111575	knob		5022914032
3	110576	symbol		5022914331



Item	Order	Description	Model	OEM
1	100079	pilot burner	GP45 GP90	5024706878
2	100701	electrode		5062606677
3	100140	ignition cable		5061003549




Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter	GP45 GP90	5060408640
2	101943	piezoelectric igniter holder		5006314278
3	101944	piezoelectric igniter protection		5006314300

A Open tops (electric)


Suitable for Ambach



Item	Order	Description	Model	OEM
1	490067	2000W/400V	EHE/70	5062502383
1	490068	2600W/400V	ERE/70, EO/70	5062502382
2	490057	3000W/400V	HEE, EH40/80, EH45/90	5062508314
2	490074	3000W/400V		5062508311



Item	Order	Description	Model	OEM
1	300174	4-position switch	EH40/80, EH45/90	5060908251
2	359829	signal lamp		5061111121
3	359050	signal lamp	EH40/80	5061111707
4	111572	knob		5022904345




Item	Order	Description	Model	OEM
1	300023	4-position switch		5060902384
2	300025	7-position switch		5060904034
3	110395	knob	EHE	5022902025
4	359069	signal lamp holder		5061103271
5	359607	glow lamp		5061103275
6	359830	signal lamp/new		5061109899




Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob	EH45/90	5022914031
3	111574	symbol		5022914336


Open tops - range cookers (electrical)




Item	Order	Description	Model	OEM
1	300023	4-position switch		5060902384
2	300025	7-position switch		5060904034
3	110356	knob 4 positions	ERE	5022901044
3	110359	knob 7 positions		5022901045
4	359131	signal lamp		5061108879
5	359127	insert lamp holder		5061108880



Item	Order	Description	Model	OEM
1	300103	4-position switch		5060902396
2	300106	7-position switch		5060904041
3	110395	knob 4 positions	HEE	5022904345
3	110396	knob 7 positions		5022904341
4	359069	signal lamp holder		5061103271
5	359607	glow lamp		5061103275
6	359830	signal lamp/new		5061109899



Item	Order	Description	Model	OEM
1	415862	1350W/400V	EKE40/70,	5060808461
2	415863	1650W/400V	EPE40, EPS40/80	5060808462
3	415866	1350W/400V	EPE80	5060808463
4	415867	1650W/400V		5060808464




Item	Order	Description	Model	OEM
1	415205	1700W/400V	EPE40D	5060808465
2	415206	2000W/400V		5060808466
3	416948	1700W/400V	EPE80D	5060808467
4	416949	2000W/400V		5060808468



Item	Order	Description	Model	OEM
1	375105	thermostat	EKE40/70, EPE40/80	5061608296, 5061608151
2	550059	retainer	EPE40D/80D	5006304040
3	300091	switch	EPS40/80	5060904057

Open tops (ceramic)



Item	Order	Description	Model	OEM
1	490008	4000W/400V	CH40/80, CH45/90	5060810556
2	490009	4000W/400V	CH40T/80T, CH45T/85T	5060810557
3	400074	control p.c.b.		5070110568



Item	Order	Description	Model	OEM
1	110392	knob		5022909877
2	359131	signal element	EKE40/70	5061108879
3	359127	insert lamp holder		5061108880
4	359050	signal lamp, 400V		5061111707




Item	Order	Description	Model	OEM
1	111577	knob		5022908120
2	359069	signal lamp holder	EPE40/80 EPE40D/80D	5061103271
3	359607	glow lamp, 400V		5061103275
4	359830	signal lamp		5061109899




Item	Order	Description	Model	OEM
1	111577	knob	EPS40/80	5022908120
2	359050	signal lamp		5061111707



Item	Order	Description	Model	OEM
1	375533	thermostat		5061614400
2	550059	retainer	EP45/90	5006304040
3	300080	switch		5060904036
4	400972	protector		3506309549



Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob		5022914031
3	111578	symbol	EP45/90	5022914340
4	359831	signal lamp/red		5061110293
5	359829	signal lamp/white		5061111121




Item	Order	Description	Model	OEM
1	375140	thermostat		5061610558
2	111577	knob	CH40/80 CH40T/80T	5022908120
3	359046	signal lamp/white		5061111708
4	359144	signal lamp/red		5061111704



Item	Order	Description	Model	OEM
1	375140	thermostat		5061610558
2	550676	gasket		5017314030
3	111573	knob	CH45/90, CH45T/90T	5022914031
4	111578	symbol		5022914340
5	359829	signal lamp/white		5061111121
6	359831	signal lamp/red		5061110293


Ovens (gas)




Item	Order	Description	Model	OEM
1	104393	burner		5016907623
2	104124	ignition bridge	GHG70	5020307627
3	n.l.a.	gas thermostat		5018902063
4	110393	knob		5022902024

A

Suitable for Ambach




Item	Order	Description	Model	OEM
1	102037	thermocouple, 1200mm	GHG70	5024102066
2	100046	pilot burner		5024703475
3	100706	electrode		5062607632



Item	Order	Description	Model	OEM
1	102037	thermocouple	HGG85/90	5024102066
2	100046	pilot burner		5024703475
3	100706	electrode		5062607632
4	100003	piezoelectric igniter		5060403707



Item	Order	Description	Model	OEM
1	104139	burner	GRG70	5016908867
2	101076	gas thermostat		5018908975
3	110351	knob		5022908973



Item	Order	Description	Model	OEM
1	104139	burner	GHG/80	5016908867
2	101916	Eurosit controller		3518912730



Item	Order	Description	Model	OEM
1	102044	thermocouple, 1200mm	GRG70	5024108855
2	100046	pilot burner		5024703475
3	100706	electrode		5062607632
4	100003	piezoelectric igniter		5060403707
5	100002	piezoelectric igniter		5060408690



Item	Order	Description	Model	OEM
1	102044	thermocouple, 1200mm	GHG/80	5024108855
2	100046	pilot burner		5024703475
3	100706	electrode		5062607632
4	100009	piezoelectric igniter		5060408640



Item	Order	Description	Model	OEM
1	104397	burner	GB90	5016914274
2	101915	Eurosit controller		5018900942
3	102042	thermocouple, 750mm		5024114564



Item	Order	Description	Model	OEM
1	104393	burner	HGG85/90	5016907623
2	104124	ignition bridge		5020307627
3	n.l.a.	gas thermostat		5018902072
4	110094	knob		5022904331




Item	Order	Description	Model	OEM
1	100079	pilot burner	GB90	5024706878
2	100701	electrode		5062606677
3	100009	piezoelectric igniter		5060408640



Item	Order	Description	Model	OEM
1	100079	pilot burner		5024706878
2	100701	electrode		5062606677
3	100009	piezoelectric igniter	GB90	5060408640
4	101943	piezoelectric igniter holder		5006314278
5	101944	piezoelectric igniter protection		5006314300


Ovens (electric)



Item	Order	Description	Model	OEM
1	415372	1500W/400V	EHE 70	5060804027
2	415859	3500W/400V		5060804028




Item	Order	Description	Model	OEM
1	375553	thermostat		5061602948
2	110134	knob	GZE70 EHE70	5022904315
3	359069	signal lamp holder	GHE70	5061103271
4	359607	glow lamp	HGE85/90 HEE85/90	5061103275
5	359830	signal lamp		5061109899




Item	Order	Description	Model	OEM
1	415860	1500W/400V	EKE/70	5060808561
2	415861	3000W/400V		5060825601



Item	Order	Description	Model	OEM
1	375553	thermostat		5061602948
2	110369	knob	EKE70	5022901048
3	359131	signal element	EO70 GRE70	5061108879
4	359127	insert lamp holder		5061108880
5	359050	signal lamp		5061111707



Item	Order	Description	Model	OEM
1	415864	2000W/400V	EPE 80	5060804349
2	415865	3000W/400V		5060804348



Item	Order	Description	Model	OEM
1	415864	2000W/400V	EPSE 80	5060804349
2	415861	3000W/400V		5060825601




Item	Order	Description	Model	OEM
1	375553	thermostat		5061618075
2	550059	retainer	EPSE 80	5006304040
3	300175	switch		5060904057




Item	Order	Description	Model	OEM
1	110134	knob		5022904315
2	359046	signal lamp/white	EPSE 80	5061111709
3	359050	signal lamp/yellow		5061111707

A

Suitable for Ambach



Item	Order	Description	Model	OEM
1	415864	2000W/400V	UBE/90	5060804349
2	416950	3000W/400V		5060815275



Item	Order	Description	Model	OEM
1	375553	thermostat	UBE/90	5061618075
2	550059	retainer		5006304040
3	300080	switch		5060904036
4	359830	signal lamp/yellow		5061109899
5	359829	signal lamp/white		5061111121



Item	Order	Description	Model	OEM
1	550676	gasket	UBE/90	5017314030
2	111573	knob		5022914031
3	111579	symbol		5022914339

Ovens (mechanical)




Item	Order	Description	Model	OEM
1	700006	hinge/right	universal	5012002196
2	700007	hinge/left		5012002108
3	700001	body section		5006302092




Item	Order	Description	Model	OEM
1	700400	hinge/right	GB/90 UBE/90	3512016349
2	700401	hinge/left		3512016350
3	700402	spacer ring		3031414396
4	700403	spring		5004717043


Hot cupboards (electric)



Item	Order	Description	Model	OEM
1	415852	800W/230V	series 85/90	5060808748
1	415853	800W/400V		5060807674
2	375555	thermostat		5061608580
3	110059	knob		5022904313



Item	Order	Description	Model	OEM
1	416976	1800W/230V	System Ecoline series S	5060809912
2	601054	fan		5062114289
2	375549	safety thermostat		5061603920



Item	Order	Description	Model	OEM
1	375546	thermostat	System Ecoline series S	5061618077
2	300175	switch		5060904057
3	110099	knob		5022904313




Item	Order	Description	Model	OEM
1	375555	thermostat	System UBW/45/90	5061608580
2	111581	knob		5022914334
3	359046	signal lamp, ø13		5061111708
4	359829	signal lamp, ø16		5061111121



Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob	UBW/90	5022914031
3	111580	symbol		5022917337

Fry tops (gas)




Item	Order	Description	Model	OEM
1	104149	burner		5016907865
2	104124	ignition bridge	GBP 35	5020307627
3	n.l.a.	gas thermostat	GBP 70	5018902560
4	110355	knob		5022904381




Item	Order	Description	Model	OEM
1	102033	thermocouple, 320mm		5024108059
2	100046	pilot burner	GBP 35	5024703475
3	100706	electrode	GBP 70	5062607632
4	100003	piezoelectric igniter		5060403707




Item	Order	Description	Model	OEM
1	104167	burner		5016908868
2	101076	gas thermostat	GUG 40 GUG 70	5018908975
3	110351	knob		5022908973




Item	Order	Description	Model	OEM
1	102040	thermocouple, 500mm		5024107489
2	100079	pilot burner	GUG 40	5024706878
3	100701	electrode	GUG 70	5062606677
4	100002	piezoelectric igniter		5060408690



Item	Order	Description	Model	OEM
1	104165	burner		5016901907
2	104169	ignition bridge		5020302579
3	n.l.a.	gas thermostat	GG40	5018902072
3	n.l.a.	gas thermostat (chromium-plated)	GG80	5018902077
4	110355	knob		5022904381



Item	Order	Description	Model	OEM
1	102034	thermocouple, 500mm		5024102394
2	100079	pilot burner	GG40	5024706878
3	100701	electrode	GG80	5062706677
4	100003	piezoelectric igniter		5060403707



Item	Order	Description	Model	OEM
1	104167	burner		5016908868
2	101916	Eurosit controller	GBP 40 GBP 80	3518912730
3	102040	thermocouple, 500mm		5024107489




Item	Order	Description	Model	OEM
1	100079	pilot burner		5024706878
2	100701	electrode	GBP 40 GBP 80	5062706677
3	100009	piezoelectric igniter		5060408640

A


Suitable for Ambach




Item	Order	Description	Model	OEM
1	104398	burner		5016914276
2	104124	ignition bridge	GBP45, GBP90	5020307627
3	101916	Eurosit controller		3518912730



Item	Order	Description	Model	OEM
1	416952	2000 W/230 V (outer)		5060814401
2	416953	2000 W/230 V (center)	EBP45, EBP90	5060814402
3	416954	2000 W/230 V (inner)		5060814403



Item	Order	Description	Model	OEM
1	102040	thermocouple, 400mm		5024110057
2	100079	pilot burner	GBP45, GBP90	5024706878
3	100701	electrode		5062606671



Item	Order	Description	Model	OEM
1	375017	safety thermostat	EBP35/70, GUE40/70, EBP40/80,	5061603684
2	375552	thermostat		5061607675
3	300080	switch	GE40/80, EBP45/90	5060904036




Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter		5060408640
2	101943	piezoelectric igniter holder	GBP45, GBP90	5006314278
3	101944	piezoelectric igniter protection		5006314300



Item	Order	Description	Model	OEM
1	110393	knob	EBP35/70	5022902024
2	110369	knob	GUE40/70	5022901048
3	110134	knob	GE40/80, EBP40/80	5022904315

Fry tops (electric)



Item	Order	Description	Model	OEM
1	415856	5000 W/230 V	EBP35/70	5060903508
2	415869	5000 W/230 V	GUE40/70, EBP40/80	5060903506
3	416951	6000 W/230 V	GE40/80	5060803509



Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob	EBP45/90	5022914031
3	111579	symbol		5022914339




Item	Order	Description	Model	OEM
1	359069	signal lamp holder		5061103271
2	359607	glow lamp, 400 V	EBP35/70, GE40/80	5061103275
3	359830	signal lamp		5061109899
4	301003	rocker switch	V-design	5060903316



Item	Order	Description	Model	OEM
1	359131	signal element		5061108879
2	359127	insert lamp holder	GUE40/70	5061108880
3	359050	signal lamp		5061111707
4	301003	rocker switch	V-design	5060903316




Item	Order	Description	Model	OEM
1	359050	signal lamp, yellow, 400V	EBP40/80	5061111707
2	359046	signal lamp, white, 400V		5061111709
3	359829	signal lamp, white, 230V	EBP45/90	5061111121
4	359834	signal lamp, yellow, 230V		5061109898




Item	Order	Description	Model	OEM
1	379257	transformer, 230V/12VDC		5062807686
2	379042	elctronic controller, 12VDC, 250 C	EBP_V, GUE_V, GE_V	5061608159
3	379099	sensor		5024107164

Multi bratt pans (electric)



Item	Order.	Description	Model	OEM
1	416955	500W/230V		5060811140
2	416961	1500W/230V		5060814355
3	375017	safety thermostat (until 10.'99)	EUB45/90	5061603684 5061616223



Item	Order	Description	Model	OEM
1	359829	signal lamp, white, 230V		5061111121
2	359834	signal lamp, yellow, 230V	EUB45/90	5061109898
3	375554	thermostat		5061618076
4	300175	switch		5060904057



Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob	EUB45/90	5022914031
3	111579	symbol		5022914339

Lava rock grills (gas)




Item	Order	Description	Model	OEM
1	104399	burner	GLG40/80,	5016911984
2	101949	gas tap	GLG45/90	5018909180
3	111570	knob		5022908810
4	100009	piezoelectric igniter	GLG40/80	5060408640



Item	Order	Description	Model	OEM
1	101951	gas tap		5018914348
2	111575	knob	GLG45, GLG90	5022914032
3	111576	symbol		5022914331



Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter		5060408640
2	101943	piezoelectric igniter holder	GLG45, GLG90	5006314278
3	101944	piezoelectric igniter protection		5006314300




Item	Order	Description	Model	OEM
1	102040	thermocouple 500		5024107489
2	100859	pilot burner	GLG40/80, GLG45/90	5024716410
3	100701	electrode		5062606677


Pasta cookers (gas)




Item	Order	Description	Model	OEM
1	104400	burner		5016914275
2	101949	gas tap	GPK40	5018909180
3	111570	knob		5022908810



Item	Order	Description	Model	OEM
1	102040	thermocouple		5024107489
2	100079	pilot burner	GPK40	5024706878
3	100701	electrode		5062606677
4	100009	piezoelectric igniter		5060408640




Item	Order	Description	Model	OEM
1	104400	burner		5016914275
2	101950	gas tap	GUK45	3018916600
3	111575	knob		5022914032
4	111576	symbol		5022914331



Item	Order	Description	Model	OEM
1	102040	thermocouple		5024107489
2	100079	pilot burner	GUK45	5024706878
3	100701	electrode		5062606677
4	100009	piezoelectric igniter		5060408640

Pasta cookers (electric)




Item	Order	Description	Model	OEM
1	415773	6000W/230 V	CPE35/70	5060807386
2	416959	8000W/230 V	EPK40, EUK45	5060814407
3	375545	safety thermostat	CPE35/70,	5061603828
4	300104	switch	EPK40, EUK45	5060909122



Item	Order	Description	Model	OEM
1	110356	knob		5022901044
2	359131	signal element		5061108879
3	359127	insert lamp holder	CPE35/70	5061108880
4	359050	signal lamp		5061111707



Item	Order	Description	Model	OEM
1	110395	knob	EPK40	5022904345
2	359050	signal lamp, 400V		5061111707




Item	Order	Description	Model	OEM
1	550676	gasket	EUK45	5017314030
2	111573	knob		5022914031
3	111574	symbol		5022914336
4	359829	signal lamp, 230V		5061111121




Item	Order	Description	Model	OEM
1	970377	390x140x175 mm (1/3)	universal	5020801593
2	970378	160x290x175 mm (1/3)		5020801594
3	970379	160x140x175 mm (right 1/6)		5020800296
4	970380	160x140x175 mm (left 1/6)		5020800297

Bains-marie (electric)




Item	Order	Description	Model	OEM
1	415851	2000W/230V	BMW35/70	5060802391
2	415688	2000W/230V	BUC40/70	5060801490
3	415612	2000W/400V	BEW40/80	5060802200




Item	Order	Description	Model	OEM
1	416957	2000 W/230V	EBM40/80	5060811860
2	416958	2000 W/230V	EBM45/90	5060814436




Item	Order	Description	Model	OEM
1	375143	thermostat	BMW35/70	5061608152
2	110395	knob		5022902025
3	359069	signal lamp holder		5061103271
4	359607	glow lamp		5061103275



Item	Order	Description	Model	OEM
1	375629	thermostat + switch	BUC40/70	5061603162
2	110367	knob		5022901046
3	359131	signal element, 400V		5061108879
4	359127	insert lamp holder		5061108880



Item	Order	Description	Model	OEM
1	375001	thermostat (old series)	BEW40/80	5061602949
2	375555	thermostat		5061608580
3	110099	knob		5022904313
4	359069	signal lamp holder		5061103271
5	359607	glow lamp		5061103275




Item	Order	Description	Model	OEM
1	375546	thermostat	EBM40/80	5061618077
2	300175	switch		5060904057
3	110099	knob		5022904313
4	359146	signal lamp, yellow, 400 V		5061111706




Item	Order	Description	Model	OEM
1	375555	thermostat + switch		5061608580
2	550676	gasket		5017314030
3	111573	knob	EBM45/90	5022914031
4	111580	symbol		5022914337
5	359829	signal lamp, 230V		5061111121


Fryers (gas)




Item	Order	Description	Model	OEM
1	104401	burner	GY40/FRG1	5016908866
2	104402	burner	GF40/FG1-40	5016906679
3	104403	burner	GF1-40/45, GF2-60-ECO, GF2-60-System	




Item	Order	Description	Model	OEM
1	101775	Composit controller		5018902617
2	390190	thermostat	GF40	5061603922
3	110106	knob		5022904314
4	301003	switch		5060903316




Item	Order	Description	Model	OEM
1	101114	Minisit controller	GY40	5018907490
2	101126	Eletrosit gas valve	FG1-40	5018902787
3	101002	ignition unit		5060402386




Item	Order	Description	Model	OEM
1	101188	Eurosit controller	GF1-40, GF2-60 ECO	5018916798
2	101162	Novasit gas valve	GF1-45, GF2-60 System	5018909590



Item	Order	Description	Model	OEM
1	379392	thermostat	FG1-40	5020404263
2	390191	safety thermostat	GF40, GY40, FG1-40	5061603921
3	375575	safety thermostat	GF1-40, GF2-60 ECO	5061614325




Item	Order	Description	Model	OEM
1	541073	pressure switch		5061309598
2	375310	thermostat	GF1-45, GF2-60 System	5061610987 5061611125
3	300080	switch		5060904036




Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob		5022914031
3	111582	symbol	GF1-45, GF2-60 System	5022914338
4	359829	signal lamp, white, 230V		5061111121
5	359834	signal lamp, yellow, 230V		5061109898



Item	Order	Description	Model	OEM
1	101577	ignition control module		5060409548
2	101788	ignition electrode	GF1-45, GF2-60 System	3562614387
3	101789	monitoring electrode		3562614388



Item	Order	Description	Model	OEM
1	102069	thermocouple with interrupter	GF40, GY40, FG1-40	5024108086
2	102013	extension		5024108084
3	101265	interrupter		5024105606
4	102040	thermocouple	GF1-45, GF2-60 ECO	5024107489



Item	Order	Description	Model	OEM
1	100079	pilot burner	GF40, GY40, FG1-40, GF1-40, GF2-60 ECO	5024706878 5024706678
2	100701	electrode		5062606677
3	100003	piezoelectric igniter	GF40	5060403707
4	100002	piezoelectric igniter	GY40, GF1-40, GF2-60 ECO	5060408690


Fryers (electric)




Item	Order	Description	Model	OEM
1	415868	5000W/230V	EF40, EF2-40, EY40, EY2-40	5060803942 3560810641
2	415857	5000W/230V	FE40, FE2-40	5060805421 3560810651
3	415898	7500W/230V	EF1-40 ECO, EF2-40 ECO, EF1-45, EF2-45	5060811194



Item	Order	Description	Model	OEM
1	375016	safety thermostat		5061603893
2	550270	thermostat pocket	EF40, EF2-40, FE40, FE2-40, FE2-80	5028600827
3	359069	signal lamp holder		5061103271
4	359607	glow lamp		5061103275
5	359830	signal lamp		5061109899



Item	Order	Description	Model	OEM
1	379257	transformer, 220V/12VDC	EY40E, EY2-40E, FE40E, FE2-40E, FE2-80E	5062807686
2	379255	electronic controller, 12VDC		5061607180
3	379111	sensor		5024107685




Item	Order	Description	Model	OEM
1	375550	safety thermostat		5061603878
2	301003	switch	EY40E, EY2-40E, FE40E, FE2-40E, FE2-80E	5060903316
3	346273	magnetic switch		5060909191




Item	Order	Description	Model	OEM
1	375022	thermostat	EF40, EF2-40, FE40, FE2-40, FE2-80	5061608750
2	110395	knob (zero mark)	EF40, EF2-40	5022902025
3	110106	knob (up to 200 C)	FE40, FE2-40, FE2-80	5022904314




Item	Order	Description	Model	OEM
1	375551	safety thermostat		5061610988
2	359046	signal lamp, white, 400V	EF1-40 ECO, EF2-40 ECO,	5061111708
3	359146	signal lamp, yellow, 400V	EF2	5061111706
4	345041	micro switch		5060909894



Item	Order	Description	Model	OEM
1	375310	thermostat	EF1-40 ECO,	5061610987
2	300107	switch	EF2-40 ECO,	5060910023
3	111583	knob	EF2	5022909977



Item	Order	Description	Model	OEM
1	375551	safety thermostat (from 10.'97)		5061610988 5061611126
2	359829	signal lamp, white, 230V		5061111121
3	359834	signal lamp, yellow, 230V	EF1-45, EF2-45	5061109898
4	345041	micro switch		5060909894



Item	Order	Description	Model	OEM
1	375310	thermostat	EF1-45, EF2-45	5061610987 5061611125
2	300107	switch		5060910023



Item	Order	Description	Model	OEM
1	550676	gasket	EF1-45,	5017314030
2	111573	knob	EF2-45	5022914031
3	111582	symbol		5022914338

Fryer baskets




Item	Order	Description	Model	OEM
1	970146	365x140x110mm	GF40, EY2-40	5020802413
2	970381	365x140x110mm (CNS)	GY40, FG1-40, FE2-40	5020804334




Item	Order	Description	Model	OEM
1	970382	330x140x140mm	GF1-40, EF1-40, GF2-40, EF2-40, GF1-45, EF1-45, GF2-45, EF2-45	5020811177
2	970383	330x220x140mm	GF2-60	5020810956

Tilting bratt pans (gas)




Item	Order	Description	Model	OEM
1	104149	burner	KBGH-70, TPG-70	5016907865
2	104164	ignition bridge		5020305523
3	104167	burner	TPG80	5016908868
4	104404	ignition bridge		5020309395




Item	Order	Description	Model	OEM
1	104165	burner	KHG90, GKM50	5016901907
2	104405	ignition bridge		5020306250
3	104406	ignition bridge	GKM50	5020311641
4	104407	burner	GKB120/150	5016914273
5	104408	ignition bridge		3520314587
6	104409	ignition bridge	GKB150	3520314588




Item	Order	Description	Model	OEM
1	101096	gas tap	KBGH-70, TPG-70	5018903683
2	111571	knob		5022907196
3	110066	knob screw	TPG-70	3009600005
4	102075	thermocouple		5024102394




Item	Order	Description	Model	OEM
1	100046	pilot burner	KBGH-70, TPG-70	5024703475
2	100706	electrode		5062607632
3	100003	piezoelectric igniter		5060403707



Item	Order	Description	Model	OEM
1	101162	Novasit gas valve	TPG80	5018909590
2	101165	ignition control module		5060409599
3	101790	ignition electrode		3562609588
4	101791	monitoring electrode		3562609589



Item	Order	Description	Model	OEM
1	375590	thermostat + switch	TPG80	5061602948
2	110396	knob		5022904315
3	541073	pressure switch		5061309598



Item	Order	Description	Model	OEM
1	346284	limit switch	TPG80	5060909930
2	359131	signal element		5061108879
3	359127	insert lamp holder		5061108880
4	359050	signal lamp		5061111707




Item	Order	Description	Model	OEM
1	n.l.a.	gas thermostat		5018902072
2	110094	knob	KHG-90	5022904331
3	102075	thermocouple 450		5024102394



Item	Order	Description	Model	OEM
1	100046	pilot burner		5024703475
2	100706	electrode	KHG-90	5062607632
3	100003	piezoelectric igniter		5060403707




Item	Order	Description	Model	OEM
1	101162	Novasit gas valve		5018909590
2	101577	ignition control module	GKB-120, GKB150,	5060409548
3	102167	ignition electrode	GKB120E, GKB150E	3562614697
4	102168	monitoring electrode		3562614698



Item	Order	Description	Model	OEM
1	101792	Eurosit controller	GK50, GKM50	3518912246
2	102040	thermocouple 400		5024100057



Item	Order	Description	Model	OEM
1	541181	pressure switch	GKB-120, GKB150,	5061315480
2	346285	limit switch	GKB120E, GKB150E	5060909748
3	375017	safety thermostat		5061616223




Item	Order	Description	Model	OEM
1	359829	signal lamp, white		5061111121
2	359834	signal lamp, yellow	GKB120, GKB150	5061109898
3	375554	thermostat		5061618076
4	300175	switch		5060904057




Item	Order	Description	Model	OEM
1	100079	pilot burner		5024706878
2	100701	electrode	GK50, GKM50	5062606677
3	100009	piezoelectric igniter		5060408640




Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob	GKB120, GKB150	5022914031
3	111579	symbol		5022914339



Item	Order	Description	Model	OEM
1	346277	push button		5060919757
2	346276	contactor block		5060919758
3	346275	lamp element	GKB120E, GKB150E	5061119760
4	359606	glow lamp, 230V		5061103274
5	400988	transformer		5062808246




Item	Order	Description	Model	OEM
1	346278	push button (reset)		5018619756
2	346276	contactor block	GKB120, GKB150,	5060919758
3	346275	lamp element	GKB120E, GKB150E	5061119760
4	359606	glow lamp		5061103274




Item	Order	Description	Model	OEM
1	400973	display p.c.b.	GKB120,	5062909870
2	400974	fascia	GKB150, GKB120E,	5011814552
3	379393	sensor	GKB150E	5024109875


Tilting bratt pans (electric)



Item	Order	Description	Model	OEM
1	415870	7500W/230V	TPE70, KBHE70, KME50	5060807220
2	415900	9000W/230V	EKM50	5060807221



Item	Order	Description	Model	OEM
1	416960	9000W/230V	TPE80	5060808751
2	415901	12000W/230V	KHE90, KME90	5060803648




Item	Order	Description	Model	OEM
1	416961	1500W/230V	EKB120/150, EKBD150	5060814355
2	416962	1500W/400V	EKBD125	5060817107



Item	Order	Description	Model	OEM
1	375017	safety thermostat	KBHE70,	5061603684
2	359069	signal lamp holder	TPE70, KME50,	5061103271
3	359607	glow lamp	KME90,	5061103275
4	359830	signal lamp	KHE90	5061109899




Item	Order	Description	Model	OEM
1	375017	safety thermostat		5061603684
2	359131	signal element		5061108879
3	359127	insert lamp holder, yellow	TPE80	5061108880
4	359225	insert lamp holder, white		5061111119




Item	Order	Description	Model	OEM
1	375017	safety thermostat (until 10.'03)	EKM50,	5061603684
			EKB120,	5061616223
2	359829	signal lamp/white	EKB150	5061111121
3	359834	signal lamp/yellow		5061109898




Item	Order	Description	Model	OEM
1	550676	gasket		5017314030
2	111573	knob	EKB120, EKB150	5022914031
3	111579	symbol		5022914339




Item	Order	Description	Model	OEM
1	375590	thermostat + switch	KBHE70,	5061602948
2	110134	knob	TPE70, KME50/90,	5022904315
3	346284	limit switch	KHE90	5060909930



Item	Order	Description	Model	OEM
1	345041	micro switch	EKBD_	5060909894
2	346274	micro switch		5060917629




Item	Order	Description	Model	OEM
1	375590	thermostat + switch	TPE80	5061602948
2	110369	knob		5022901048




Item	Order	Description	Model	OEM
1	400973	display p.c.b.		5062909870
2	400974	fascia	EKB120E, EKB150E	5011814552
3	379393	sensor		5024109875
4	400988	transformer		5062808246




Item	Order	Description	Model	OEM
1	375590	thermostat + switch (until 7.'99)		5061602948
2	375553	thermostat	EKM50,	5061618075
3	300091	switch	EKB120, EKB150	5060904057
4	110134	knob	EKM50	5022904315




Item	Order	Description	Model	OEM
1	346277	push button		5060919757
2	346276	contactor block	EKB120E/E II, EKB150E/E II,	5060919758
3	346275	lamp element	EKBD125E, EKBD160E	5061119760
4	359606	glow lamp, 230V		5061103274



Item	Order	Description	Model	OEM
1	400975	main module (standard)		3562916938
1	400976	main module (RS485)		3562917713
2	400977	EPROM (Standard)		5062916941
2	400978	EPROM (RS485)	EKB120E II, EKB150E II	5062916935
3	400979	control p.c.b.		5062916945
4	400980	fascia		5011810838
5	379393	sensor		5024109875
6	400988	transformer		5062808246




Item	Order	Description	Model	OEM
1	400983	main module (Standard)		3562916937
1	400984	main module (RS485)		3562917712
2	400985	EPROM (standard)		5062916940
2	400986	EPROM (RS485)		5062916934
3	400979	control p.c.b.	EKBD125E, EKBD160E	5062916945
4	400987	fascia		5011817558
5	379394	sensor		5024117582
6	379393	sensor		5024109875
7	400988	transformer		5062812746



Item	Order	Description	Model	OEM
1	690852	hand wheel	KHG90, KHE90,	2020100286
2	693223	gearbox	EKH90, GKH90	5026904330




Item	Order	Description	Model	OEM
1	700404	lid spring	KBHG70, KBHE70	5004705557
2	700405	lid spring	TPG80, TPE80	5004705386
3	700406	lid spring	EKM50, GKM50, EKH90, GKH90, EKM90, GKM90	5004707073
4	700407	lid spring	EKB120/150, EKB120E/150E, GKB120/150, GKB120E/150E	5004714039




Item	Order	Description	Model	OEM
1	700408	tilt spring	EKB120/120E, GKB120/150E	5004715273
2	700409	tilt spring	EKB150, GKB150	5004715274
3	541334	pressure gauge	EKBD	5027210517

Tilting bratt pans (motor driven)




Item	Order	Description	Model	OEM
1	346280	contactor block 1 NO/NC		5060906194
1	345640	contactor block 1 NO	KME50, KMG50, EKM50, EKM50	5060902730
2	301204	rotary control switch		5060901909
3	346283	limit switch	KME50, KMG50	5060907229
4	346284	limit switch		5060909930
5	346279	swing lever	EKM50, GKM50	5060909440

Tilting bratt pans (mechanical)




Item	Order	Description	Model	OEM
1	693221	crank	KBHG70, KBHE70, TPE70/80, TPG70/80	2005600284
2	693222	gearbox		5026905539


Suitable for Ambach



Item	Order	Description	Model	OEM
1	346282	contactor block		5060906309
2	346348	push button	KME90, KMG90	5018606295
3	346283	limit switch		5060907229
4	n.l.a.	starting roller		5060907236



Item	Order	Description	Model	OEM
1	346280	contactor block	EKM90, GKM90	5060911266
2	346281	push button		5018611265
3	346285	limit switch	EKM90, GKM90,	5060909748
4	346279	swing lever	EKB_, GKB_, EKBD_	5060909440



Item	Order	Description	Model	OEM
1	500612	spindle motor	KME50, KMG50,	5061207233
1	500613	spindle motor	EKM50, GKM50	5061214801
1	500614	spindle motor	EKB_, GKB_, EKBD_	5061214601
2	500615	gear motor (until 2.'98)		5061207235
2	500617	gear motor (from 2.'98)	KME90, KMG90,	5061211730
3	358513	motor protection circuit interrupter	EKB_, GKB_, EKBD_	5060909759

Tilting bratt pans (water)




Item	Order	Description	Model	OEM
1	540940	inlet pipe	KME50, KMG50, KHE90, KHG90, EKM50, GKM50	5029406192
2	540950	inlet pipe	EKH90, GKH90, EKM90, GKM90	5000508009
3	540941	inlet tap	KHE90, KHG90, EKH90, GKH90	5018003414




Item	Order	Description	Model	OEM
1	540912	mixer tap	EKB_, GKB_	5024550861
2	540778	inlet pipe	EKB_E, GKB_E, EKBD	5000510477 5000513764
3	540911	safety valve	EKBD	5018017524 5018018147
4	540949	pressure relief valve		5018117691



Item	Order	Description	Model	OEM
1	370005	solenoid valve		5018106152
2	345640	contactor block	KME50, KMG50	5060902730
3	346349	push button		5018606295



Item	Order	Description	Model	OEM
1	370092	solenoid valve	EKM50, GKM50,	5018106153
2	346280	contactor block	EKBD_, EKB_E II	5060911266
3	346281	push button	EKM50, GKM50	5018611265



Item	Order	Description	Model	OEM
1	370092	solenoid valve	EKB_E, GKB_E	5018106153
2	380088	stepping relay		5061410308


Boiling pans (gas)

A


Suitable for Ambach




Item	Order	Description	K7G35	K7G50	BPG50	KKG75	KKG100	KKG130	GKS60	GKS80	GKS100	GKS150	GSK40	GSK60	GSK80	GSK100	GSK150	GNKG150	GNKG230	OEM
1	104168	burner	X	X		X	X	X												5016907365
2	104148	burner			X															5016907861
3	104410	burner							X				X	X						5016914561
4	104411	burner								X	X	X			X	X	X			5016914562
5	104170	ignition bridge	X	X																5020307355
6	104169	ignition bridge				X	X	X												5020307369




Item	Order	Description	K7G35	K7G50	BPG50	KKG75	KKG100	KKG130	GKS60	GKS80	GKS100	GKS150	GSK40	GSK60	GSK80	GSK100	GSK150	GNKG150	GNKG230	OEM
1	101953	gas tap	X	X																5018907199
2	101954	gas tap				X	X	X												5018907198
3	111570	knob	X	X		X	X	X												5022908810 5022906228
4	101126	Elettrosit gas valve			X															5018907227
5	101908	Novasit gas valve							X	X	X	X								5018900703
6	101914	Novasit gas valve											X	X	X	X	X			3518916399
7	541181	pressure switch				X	X	X	X	X	X	X	X	X	X	X	X			5061315480 5061307558
8	541073	pressure switch											X	X	X	X	X			5061309598
9	101577	ignition control module											X	X	X	X	X			5060409548



Item	Order	Description	K7G35	K7G50	BPG50	KKG75	KKG100	KKG130	GKS60	GKS80	GKS100	GKS150	GSK40	GSK60	GSK80	GSK100	GSK150	GNKG150	GNKG230	OEM	
1	100079	pilot burner	X	X	X	X	X	X	X	X	X	X									5024706878
2	100701	electrode	X	X	X	X	X	X	X	X	X	X									5062606677
3	100003	piezoelectric igniter	X	X		X	X	X													5060403767
4	100009	piezoelectric igniter							X	X	X	X									5060408640
5	101265	thermocouple interrupter	X	X		X	X	X													5024105819
6	102040	thermocouple, 400mm	X	X		X	X	X													5024107382
7	102069	thermocouple, 600mm			X																5024108086
7	102070	thermocouple, 1000mm							X	X	X	X									5024108078
8	101012	ignition unit			X																5060401734
9	101312	interrupter			X																5060402366
10	102013	thermocouple extension			X																5024108084
11	102165	ignition electrode											X	X	X	X	X				3562615503
12	102166	monitoring electrode											X	X	X	X	X				3562615504




Item	Order	Description	K7G35	K7G50	BPG50	KKG75	KKG100	KKG130	GKS60	GKS80	GKS100	GKS150	GSK40	GSK60	GSK80	GSK100	GSK150	GNKG150	GNKG230	OEM	
1	375549	safety thermostat	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X				5061603920
1	375544	safety thermostat																			5061600808
2	379914	thermostat				X	X	X													5020704262
3	375548	thermostat											X	X	X	X	X				5061609772
4	101948	gas solenoid valve				X	X	X													5018106116
5	375547	thermostat							X	X	X	X	X	X	X	X	X				5061603938
6	300080	switch							X	X	X	X	X	X	X	X	X				5060904036
7	110099	knob							X	X	X	X									5022904313
8	359046	signal lamp/white, 230V							X	X	X	X									5061111708
9	359146	signal lamp/yellow, 230V							X	X	X	X									5061111706



Item	Order	Description	K7G35	K7G50	BPG50	KKG75	KKG100	KKG130	GKS60	GKS80	GKS100	GKS150	GSK40	GSK60	GSK80	GSK100	GSK150	GNKG150	GNKG230	OEM
1	550676	gasket											X	X	X	X	X			5017314030
2	111573	knob											X	X	X	X	X			5022914031
3	111580	symbol											X	X	X	X	X			5022914337
4	416200	pilot heating											X	X	X	X	X			5024709751
5	550538	thermostat pocket											X	X	X	X	X			3500514648
6	550678	reducing nipple											X	X	X	X	X			3006315427
7	359829	signal lamp/white											X	X	X	X	X			5061111121
8	359834	signal lamp/yellow											X	X	X	X	X			5061109898
9	359831	signal lamp/red											X	X	X	X	X			5061110293
10	359835	signal lamp/green											X	X	X	X	X			5061113846

Boiling pans (electric)



Item	Order	Description	K7E35	K7E50	BPE50	KKE75	KKE100	KKE130	EKS40	EKS60	EKS80	EKS100	EKS150	KSKE50	KSKE100	OEM
1	416966	8000W/230V	X	X												5060807398
2	415674	4500W/230V				X	X	X			X					5060810063 5060807384
3	415773	6000W/230V				X	X	X	X	X	X	X	X			5060810064 5060807386
4	415854	8000W/230V			X									X	X	5060809979 5060807387




Item	Order	Description	ESK40	ESK60	ESK80	ESK100	ESK150	GNKE100	GNKE150	GNKE230	EKK40	EKK100	EKK150	EKK200	EKK250	OEM
1	415674	4500V	X	X												5060810063
2	415773	6000V			X	X	X		X		X	X	X			5060810064
3	415854	8000V						X	X	X			X	X		5060809979
4	416967	10000V						X	X					X	X	5060809980
5	416200	315W/230V	X	X	X	X	X	X	X	X	X	X	X	X	X	5024709751







Item	Order	Description	K7E35	K7E50	BPE50	KKE75	KKE100	KKE130	EKS40	EKS60	EKS80	EKS100	EKS150	KSKE50	KSKE100	OEM
1	300103	switch	X	X										X	X	5060902396
2	110395	knob	X	X		X	X	X	X	X	X	X	X	X	X	5022904345
3	375143	thermostat	X	X												5061608152
4	110099	knob	X	X					X	X	X	X	X			5022904313
5	300104	switch			X											5060909122
6	110356	knob			X											5022901044
7	375547	thermostat			X				X	X	X	X	X			5061603938
8	110367	knob			X											5022901046
9	301097	switch				X	X	X	X	X	X	X	X			5060904035





Item	Order	Description	K7E35	K7E50	BPE50	KKE75	KKE100	KKE130	EKS40	EKS60	EKS80	EKS100	EKS150	KSKE50	KSKE100	OEM
1	379914	thermostat				X	X	X								5020704262
2	541181	pressure switch	X	X	X	X	X	X						X	X	5061307558
3	359069	signal lamp holder	X	X		X	X	X								5061103271
4	359607	glow lamp	X	X		X	X	X								5061103275
5	375545	safety thermostat			X	X	X	X	X	X	X	X	X	X	X	5061603828
6	359131	signal element			X											5061108879
7	359127	insert lamp holder			X											5061108880
	no longer available	electronic controller												X	X	5061607157
	no longer available	sensor												X	X	5024107156



Item	Order	Description	K7E35	K7E50	BPE50	KKE75	KKE100	KKE130	EKS40	EKS60	EKS80	EKS100	EKS150	KSKE50	KSKE100	OEM
1	541181	pressure switch							X	X	X	X	X			5061315480
2	359046	signal lamp/white							X	X	X	X	X			5061111708
3	359146	signal lamp/yellow							X	X	X	X	X			5061111706
4	359144	signal lamp/red							X	X	X	X	X			5061111704
5	375548	thermostat							X	X	X	X	X			5061609772



Item	Order	Description	ESK40	ESK60	ESK80	ESK100	ESK150	GNKE100	GNKE150	GNKE230	EKK40	EKK100	EKK150	EKK200	EKK250	OEM
1	301097	switch	X	X	X	X	X	X	X	X	X	X	X	X	X	5060904035
2	375547	thermostat	X	X	X	X	X	X	X	X						5061603938
3	380015	energy regulator									X	X	X	X	X	5061616087
4	550676	gasket	X	X	X	X	X	X	X	X	X	X	X	X	X	5017314030
5	111573	knob	X	X	X	X	X	X	X	X	X	X	X	X	X	5022914031
6	111574	symbol/switch	X	X	X	X	X	X	X	X	X	X	X	X	X	5022914336
7	111580	symbol/thermostat	X	X	X	X	X	X	X	X						5022914337
8	111578	symbol/energy regulator									X	X	X	X	X	5022914340



Item	Order	Description	ESK40	ESK60	ESK80	ESK100	ESK150	GNKE100	GNKE150	GNKE230	EKK40	EKK100	EKK150	EKK200	EKK250	OEM
1	375548	thermostat	X	X	X	X	X	X	X	X	X	X	X	X	X	5061609772
2	541181	pressure switch	X	X	X	X	X	X	X	X	X	X	X	X	X	5061315480
3	375545	safety thermostat	X	X	X	X	X	X	X	X						5061603828
4	375544	safety thermostat									X	X	X	X	X	5061600808
5	359829	signal lamp, white	X	X	X	X	X	X	X	X	X	X	X	X	X	5061111121
6	359834	signal lamp, yellow	X	X	X	X	X	X	X	X	X	X	X	X	X	5061109898
7	359831	signal lamp, red	X	X	X	X	X	X	X	X	X	X	X	X	X	5061110293
8	359835	signal lamp, green	X	X	X	X	X	X	X	X	X	X	X	X	X	5061113846



Item	Order	Description	ESK40E	ESK60E	ESK80E	ESK100E	ESK150E	GNKE100E	GNKE150E	GNKE230E	EKK40E	EKK100E	EKK150E	EKK200E	EKK250E	OEM
1	400973	display p.c.b.	X	X	X	X	X	X	X	X	X	X	X	X	X	5062909870
2	400974	fascia	X	X	X	X	X	X	X	X	X	X	X	X	X	5011814552
3	379915	sensor	X	X	X	X	X	X	X	X	X	X	X	X	X	5024109876
4	400988	transformer	X	X	X	X	X	X	X	X	X	X	X	X	X	5062808246
5	375544	safety thermostat	X	X	X	X	X	X	X	X	X	X	X	X	X	5061600808
6	375548	thermostat	X	X	X	X	X	X	X	X	X	X	X	X	X	5061609772
7	541181	pressure switch	X	X	X	X	X	X	X	X	X	X	X	X	X	5061315480
8	346276	contactor block	X	X	X	X	X	X	X	X	X	X	X	X	X	5060919758
9	346275	lamp element	X	X	X	X	X	X	X	X	X	X	X	X	X	5061119760
10	359606	glow lamp, 230V	X	X	X	X	X	X	X	X	X	X	X	X	X	5061103274
11	346329	holder	X	X	X	X	X	X	X	X	X	X	X	X	X	5060919759
12	346277	pressure switch	X	X	X	X	X	X	X	X	X	X	X	X	X	5060919757
13	346278	button (lamp)	X	X	X	X	X	X	X	X	X	X	X	X	X	5018619756
14	359831	signal lamp (until 99)	X	X	X	X	X	X	X	X	X	X	X	X	X	5061110293


Boiling pans (water + mechanical)



Item	Order	Description	K7G35	K7G50	K7E35	K7E50	BPG50	BPE50	KKG75	KKG100	KKG150	KKK75	KKK100	KKK130	KSKE50	KSKE100	OEM
1	540950	inlet pipe	X	X	X	X	X	X	X	X	X	X	X	X			5000508009
2	540943	water faucet/red	X	X	X	X	X	X	X	X	X	X	X	X			5018003416
3	540942	water faucet/blue	X	X	X	X	X	X	X	X	X	X	X	X			5018007357
4	540913	mixer tap													X	X	6511250574
5	540920	safety group	X	X	X	X			X	X	X	X	X	X			5018007443
6	540923	safety valve					X	X									5018107454
7	540926	filling pot, 1/2"													X	X	5018107459



Item	Order	Description	K7G35	K7G50	K7E35	K7E50	BPG50	BPE50	KKG75	KKG100	KKG150	KKE75	KKE100	KKE130	KSKE50	KSKE100	OEM	
1	540080	testing tap	X	X	X	X	X	X	X	X	X	X	X	X	X	X	5018000055	
2	540011	pressure relief valve, 1/2"					X	X									5018107456	
3	540013	pressure relief valve, 3/8"													X	X	5018107460	
4	540136	drain tap, 1 1/4"	X	X	X	X	X	X								X	X	5018007352
5	540137	drain tap, 1 1/2"							X	X	X	X	X	X			5018007460	
6	541062	manometer	X	X	X	X			X	X	X	X	X	X			5027207356	
7	541334	manometer					X	X							X	X	5027209124 5027207762 3527217898	



Item	Order	Description	K7G35	K7G50	K7E35	K7E50	BPG50	BPE50	KKG75	KKG100	KKG150	KKE75	KKE100	KKE130	KSKE50	KSKE100	OEM
1	700405	lid spring							X	X	X	X	X	X			5004705386
2	111597	handle					X	X	X	X	X	X	X	X			5005607354
3	690512	lid spring													X	X	5004705253
4	110703	handle cap													X	X	5005607080
5	693223	gearbox													X	X	5026904330
6	690852	hand wheel													X	X	2020100286


A Boiling pans (water + mechanical)




Item	Order	Description	GKS60/80	GKS100/150	EKS40/60/80	EKS100/150	GJK40/60/80	GJK100/150	ESK40/60/80	ESK100/150	GKE150/250	GNKE100/150/250	EKK40/100/150	EKK200/250	ESK40E/100E/150E	ESK200E/250E	GNKE150E/250E	EKK40E/100E/150E	EKK200E/250E	OEM
1	540950	inlet pipe	X	X	X	X	X	X	X	X	X	X			X	X	X			5000508009
2	540922	water faucet	X	X	X	X	X	X	X	X	X	X								5018013782
3	540924	upper part, 1/2"	X	X	X	X	X	X	X	X	X	X								5018007381
4	540944	rosette	X	X	X	X	X	X	X	X	X	X								5022213783
5	540951	handle	X	X	X	X	X	X	X	X	X	X								5022913784
6	540946	ring/red	X	X	X	X	X	X	X	X	X	X								5031400109
7	540945	ring/blue	X	X	X	X	X	X	X	X	X	X								5031400110
8	540948	screw	X	X	X	X	X	X	X	X	X	X								5040913785
9	540947	cap	X	X	X	X	X	X	X	X	X	X								5025000108




Item	Order	Description	GKS60/80	GKS100/150	EKS40/60/80	EKS100/150	GJK40/60/80	GJK100/150	ESK40/60/80	ESK100/150	GKE150/250	GNKE100/150/250	EKK40/100/150	EKK200/250	ESK40E/100E/150E	ESK200E/250E	GNKE150E/250E	EKK40E/100E/150E	EKK200E/250E	OEM
1	540912	mixer tap											X	X						5024550861
2	540778	inlet pipe																X	X	5000508247
3	540920	safety group	X	X	X	X														5018007443
4	540080	testing tap	X	X	X	X														5018000055
5	541062	manometer	X	X	X	X														5027207356



Item	Order	Description	GKS60/80	GKS100/150	EKS40/60/80	EKS100/150	GJK40/60/80	GJK100/150	ESK40/60/80	ESK100/150	GKE150/250	GNKE100/150/250	EKK40/100/150	EKK200/250	ESK40E/100E/150E	ESK200E/250E	GNKE150E/250E	EKK40E/100E/150E	EKK200E/250E	OEM
1	540921	safety valve					X	X	X	X	X	X	X	X	X	X	X	X	X	5018015600
2	541334	manometer					X	X	X	X	X	X	X	X	X	X	X	X	X	5027210517
3	540779	thermostatic steam trap					X	X	X	X	X	X	X	X	X	X	X	X	X	5018117567
4	370092	van solenoid valve					X	X	X	X	X	X	X	X	X	X	X	X	X	5018106153
5	540925	drain cock, 1 1/2"	X	X	X	X	X	X	X	X			X	X	X	X		X	X	5018013159
6	540267	drain cock, 2"									X	X					X			5018018815 5018016320




Item	Order	Description	GKS60/80	GKS100/150	EKS40	EKS60/80	EKS100/150	GSK40	GSK60/80	GSK100/150	ESK40	ESK60/80	ESK100/150	OEM
1	690513	lid spring			X			X			X			5004714718
2	690515	lid spring	X	X		X	X		X	X		X	X	5004714695
3	693252	spring compressor	X	X	X	X	X	X	X	X	X	X	X	5001109945
4	560175	grub screw	X	X	X	X	X	X	X	X	X	X	X	5040810578




Item	Order	Description	GNKG150/250	GNKE100	GNKE150/230	EKK40/100/150	EKK200/250	ESK40E	ESK60E/80E	ESK100E/150E	GNKE100E	GNKE150E/230E	EKK40E/100E/150E	EKK200E/250E	OEM
1	690513	lid spring						X							5004714718
2	690515	lid spring		X					X	X	X				5004714695
3	690514	lid spring	X		X							X			5004709717
4	693252	spring compressor	X	X	X			X	X	X	X	X			5001109945
5	560175	grub screw	X	X	X			X	X	X	X	X			5040810578
6	700407	gas spring				X	X						X	X	5004714039
7	700408	spring coupling				X	X						X	X	5004715273

Boiling pans (motor driven)



Item	Order	Description	Model	OEM
1	346280	contactor block	EKK40/100,	5060911266
2	346281	push button	EKK150/200, EKK250	5018611265
3	358513	overload relay	EKK_, EKK_E	5060909759
4	346285	limit switch		5060909748
5	380088	contact relay	EKK_E	5061410308



Item	Order	Description	Model	OEM
1	500614	spindle motor	EKK40/100, EKK40E/100E	5061214601
2	500638	spindle motor	EKK150/200/ 250, EKK150E/ 200E/250E	5061214563



GASTROPARTS.COM



© 2020 Gastroparts Sp. J. All rights reserved.