



**GASTROPARTS**

# Ascobloc

**[EN]** Cooking

**[DE]** Kochtechnik

**[ES]** Cocción

**[FR]** Cuisson

**[IT]** Cottura

**[PL]** Obróbka termiczna

**[RU]** Термическая обработка

✉ [gastroparts@gastroparts.com](mailto:gastroparts@gastroparts.com)

☎ tel. +48 56 657 00 66

📘 [fb.com/gastroparts.global](https://fb.com/gastroparts.global)

**GASTROPARTS.COM**




## TABLE OF CONTENTS

### Open tops (gas/electric)




page 4

### Ovens (gas/electric)




page 5

### Fry tops (gas/electric)



page 5


### Bains-marie (electric)



page 6

# TABLE OF CONTENTS

## Fryers (gas/electric)




page 6

## Tilting bratt pans (electric)



page 7

## Boiling pans (electric)



page 8

## A Open tops (gas)



Item	Order	Description	Model	OEM
1	104501	burner cover (C)		9146383
2	104500	burner base (C)	AGH210/218/410	9146387
3	104511	burner gasket	AGH413/417/418	9146393
4	104502	Venturi (C)	AGH610/613	9146385
5	104520	air aeration sleeve	AGH617/618	-



Item	Order	Description	Model	OEM
1	104541	burner cover (D)		9146389
2	104505	burner base (D)	AGH210/218/410	9146388
3	104511	burner gasket	AGH413/417/418	9146393
4	104504	Venturi (D)	AGH610/613	9146391
5	104521	air aeration sleeve	AGH617/618	-



Item	Order	Description	Model	OEM
1	101529	pilot burner (complete)		-
2	101848	cover		-
3	101582	upper part	newe series	-
4	101587	gasket		-



Item	Order	Description	Model	OEM
1	101584	cap (upper part)		-
2	101583	ignition piece		-
3	101586	lower part	newe series	-
4	101284	olive, 4mm		-
5	101285	union screw, M8x1		-
6	101585	thermocouple screw connection		-



Item	Order	Description	Model	OEM
1	101831	ignition piece inlet		9146405
2	101830	ignition piece	AGH210/218/410	9146406
3	101839	thermocouple inlet	AGH413/417/418	9146407
4	101587	gasket	AGH610/613	9146402
5	101842	cover	AGH617/618	918430000



Item	Order	Description	Model	OEM
1	101843	base plate pilot burner (C)	AGH210/218/410	9146409
2	101844	base plate pilot burner (D)	AGH413/417/418	9146401
3	101835	pilot burner lower part (C)	AGH610/613	9146410
4	101834	pilot burner lower part (D)	AGH617/618	9146403




Item	Order	Description	Model	OEM
1	102218	thermocouple, 320mm		9096024
1	102220	thermocouple, 600mm	AGH210/218/410	9096025
2	n.l.a.	gas tap (EGA)	AGH413/417/418	9146372
2	n.l.a.	gas tap (EGA)	AGH610/613	9146372
3	101671	gas tap (PEL)	AGH617/618	9146369
				9146372
				9146369



Item	Order	Description	Model	OEM
1	110189	knob	AGH210/218/410	9297035
2	110550	symbol EGA	AGH413/417/418	9297026
3	110558	symbol PEL	AGH610/613	-
			AGH617/618	-

## Open tops (electric)




Item	Order	Description	Model	OEM
1	416893	cooker (double), 540 x 260mm, 5200W/230V	AEH210/218	9174102
2	300172	5-position switch	AEH410/413	9173302
3	110189	knob	AEH610/613	9297035
4	111553	symbol	AEH418/618	9297025
5	359165	signal lamp green		9295408




## Open tops/Ceramic (electrical)



Item	Order	Description	Model	OEM
1	490132	2100W/230V	AEH300/500	9174100
2	490028	2100W/230V (2-circuit)	AEH503/508 AEH700/703	8181713
3	359165	signal lamp	AEH708/308	9295408




Item	Order	Description	Model	OEM
1	380016	energy regulator, 2-circuit	AEH300/500	8183237
2	300172	5-position switch	AEH503/508 AEH700/703	9173302
3	300004	7-position switch	AEH708/308	9295403



Item	Order	Description	Model	OEM
1	110189	knob	AEH300/500	9297035
2	111555	symbol energy regulator	AEH503/508	9297022
3	110553	symbol 5-tacts	AEH700/703	9297025
4	110552	symbol seven tact	AEH708/308	9297024

## Ovens (gas)



Item	Order	Description	Model	OEM
1	105636	burner	AGH417	8152719
2	n.l.a.	gas thermostat	AGH617	9146370
3	102223	thermocouple	-	-



Item	Order	Description	Model	OEM
1	100058	pilot burner	AGH417	9290540
2	110189	knob	AGH617	9297035
3	110547	symbol	-	9294238

## Ovens (electric)




Item	Order	Description	Model	OEM
1	415995	1500W/400V	AEH413	9294281
2	359165	signal lamp/green, 230V	AEH613	9295408
3	359198	signal lamp/white, 400V	AEH503	9295409
4	390483	contact thermostat	AEH703	9294101



Item	Order	Description	Model	OEM
1	375408	thermostat with switch	AEH413	9295400
2	110189	knob	AEH613	9297035
3	110549	symbol	AEH703	9294127

## Ovens (mechanical)



Item	Order	Description	Model	OEM
1	900391	door seal/upper	-	127751.05
2	900390	door seal/side	AGH417/617	127750.05
3	700187	torsion spring	AEH413/613/ 503/703	9294387
4	601052	fan with transverse flow	-	8178463


## Fry tops (gas)



Item	Order	Description	Model	OEM
1	104501	burner cover (C)	-	9146383
2	104500	burner base (C)	AGB230	9146387
3	104511	burner gasket	AGB430	9146393
4	104502	Venturi (C)	AGB238	9146385
5	104520	air aeration sleeve	AGB438	-




Item	Order	Description	Model	OEM
1	n.l.a.	thermostat EGA	AGB230	9146399
2	110189	knob	AGB430	9297035
3	110547	symbol	AGB238	9294219
			AGB438	



Item	Order	Description	Model	OEM
1	102218	thermocouple	AGB230	9296024
2	100085	pilot burner	AGB430	9264282
3	100007	piezoelectric igniter	AGB238	9296035
			AGB438	

## Fry tops (electric)




Item	Order	Description	Model	OEM
1	416897	3500W/400V	AEB230	8160350
2	375505	thermostat (limiter function)	AEB430	8174681
3	359165	signal lamp green 230V	AEB238	9295408
4	359198	signal lamp white 400V	AEB438	9295409



Item	Order	Description	Model	OEM
1	375408	thermostat with switch	AEB230	9295400
2	110189	knob	AEB430	9297035
3	110530	symbol	AEB238	9297016
			AEB438	


## Bains-marie (electric)



Item	Order	Description	Model	OEM
1	416912	750W/230V	AEW250	8160351
2	375505	thermostat (limiter function)	AEW450/452 AEW400/408	8174681
3	359165	signal lamp/green	AEW250/450	9295408
4	359166	signal lamp/white	AEW400/452 AEW408	9295407




Item	Order	Description	Model	OEM
1	375406	thermostat with switch	AEW250	9295433
2	110189	knob	AEW450/452	9297035
3	110545	symbol	AEW400/408	9297019



Item	Order	Description	Model	OEM
1	380486	level relay, ENS	AEW400	9177191
2	400697	level sensor	AEW408	915000648

## Fryers (gas)



Item	Order	Description	Model	OEM
1	104380	burner		127678.05
2	n. l. a.	thermostat EGA	AGF124/224 AGF128/228	9146371
3	375423	safety thermostat		9296108




Item	Order	Description	Model	OEM
1	110189	knob	AGF124/224	9297035
2	110543	symbol	AGF128/228	9294219




Item	Order	Description	Model	OEM
1	100085	pilot burner	AGF124/224	9294282
2	102089	thermocouple	AGF128/228	9296034
3	100007	piezoelectric igniter		9296035

## Fryers (electric)



Item	Order	Description	Model	OEM
1	415591	2000W/230V		9294087
2	375421	safety thermostat	AEF124 AEF224	8152102
3	359165	signal lamp/green	AEF128	9295408
4	359166	signal lamp/white		9295407



Item	Order	Description	Model	OEM
1	300179	switch	AEF124	9295405
2	110189	knob	AEF224	9297035
3	110544	symbol	AEF128	8145407




Item	Order	Description	Model	OEM
1	375422	thermostat	AEF124	8152105
2	110189	knob	AEF224	9297035
3	110536	symbol	AEF128	9297020



Item	Order	Description	Model	OEM
1	345062	micro switch	AEF124/224	8177168
2	970159	fryer basket	AEF128/494	9292205


## Tilting bratt pans (electric)



Item	Order	Description	Model	OEM
1	416897	3500W/400V		8160350
2	375505	thermostat (limiter function)	AEP500	8174681
3	359165	signal lamp/green, 230V	AEP508	9295408
4	359198	signal lamp/white, 400V		9295409



Item	Order	Description	Model	OEM
1	375408	thermostat with switch	AEP500	9295400
2	110189	knob	AEP508	9297035
3	110530	symbol		9297016




Item	Order	Description	Model	OEM
1	380418	contactor	AEP500	8486100
2	346299	limit switch	AEP508	8486038





Item	Order	Description	Model	OEM
1	346271	push button		8486102
2	346272	push button lit	AEP500	8486105
3	346270	contact element	AEP508	8486101

## Boiling pans (electric)



Item	Order	Description	Model	OEM
1	415405	6000W/230V		9294203
2	418147	6000W/230V	AES060	9294496
3	415607	500W/230V	AES080	8181729




Item	Order	Description	Model	OEM
1	510562	O-ring silicone		8060842
2	510408	O-ring - EPDM	AES060 AES080	9298045
3	550002	holder		9294008



Item	Order	Description	Model	OEM
1	380015	energy regulator		8183150
2	110189	knob	AES060 AES080	9297035
3	110551	symbol		9297017



Item	Order	Description	Model	OEM
1	300113	switch		9296002
2	110189	knob	AES060 AES080	9297035
3	110539	symbol		9298003



Item	Order	Description	Model	OEM
1	541016	pressure switch		9296000
2	390143	safety thermostat	AES060	9296084
3	359165	signal lamp/green	AES080	9295408
4	359166	signal lamp/white		9295407



Item	Order	Description	Model	OEM
1	541343	manometer		8151500
2	514273	safety valve	AES060	8151701
3	514272	steam trap	AES080	8150901



Item	Order	Description	Model	OEM
1	540887	inlet pipe		8178419
2	540896	mixing valve	AES060 AES080	8151603
3	540155	drain cock		8150301



Pos.	Order	Description	Model	OEM
1	540876	cover rotating joint		





**GASTROPARTS.COM**



© 2020 Gastroparts Sp. J. All rights reserved.