



**GASTROPARTS**

# Blumauer

**[EN]** Cooking

**[DE]** Kochtechnik

**[ES]** Cocción

**[FR]** Cuisson

**[IT]** Cottura

**[PL]** Obróbka termiczna

**[RU]** Термическая обработка

✉ [gastroparts@gastroparts.com](mailto:gastroparts@gastroparts.com)

☎ tel. +48 56 657 00 66

📘 [fb.com/gastroparts.global](https://fb.com/gastroparts.global)

**GASTROPARTS.COM**




## Open tops (gas)



Item	Order	Description	Model	OEM
1	103080	burner cover C, 80mm	G20, G40, GG21	183725
2	103082	burner cover D	G60, G80,	183723
3	103081	burner cover E, 100mm		183727

## Open tops (electric)




Item	Order	Description	Model	OEM
1	490017	2000W, 400V, 180mm	E22_, E42_	180110
2	490021	2600W, 400V, 220mm	E62_	180120
3	490078	3000W, 400V, 300x300mm	universal	180131



Item	Order	Description	Model	OEM
1	100059	pilot burner		183305
2	100703	electrode	G20, G40,	
3	102219	thermocouple, 450mm	G60, G80,	183113
3	102221	thermocouple, 750mm	GG21	183114



Item	Order	Description	Model	OEM
1	300023	4-position switch	universal	180510
2	300025	7-position switch	E22, E42, E62	180511
3	110191	knob	universal	190211



Item	Order	Description	Model	OEM
1	110507	symbol, 4-tacts (in the front)	universal	190220
2	110508	symbol, 4-tacts (at the back)		190221
3	110509	symbol, 7-Takt (in the front)	E22, E42, E62	190222
4	110510	symbol, 7-Takt (at the back)		190223




Item	Order	Description	Model	OEM
1	n. l. a.	gas tap EGA		
2	101606	gas tap PEL	G20, G40,	183050, 183051,
3	101246	olive, 4mm	G60, G80,	183052, 183053,
4	100908	union screw, M10x1, 4mm	GG21	183054, 183055

## Solid tops (gas)



Item	Order	Description	Model	OEM
1	no longer available	gas tap EGA		183012
2	101620	gas tap PEL	GG01, GG02, GG21	183012
3	110191	knob		190210
4	110504	symbol		190231



Item	Order	Description	Model	OEM
1	110191	knob	G20, G40,	190210
2	110501	symbol/in the front	G60, G80,	190237
3	110502	symbol/at the back	GG21	190236




Item	Order	Description	Model	OEM
1	100059	pilot burner		183305
2	100703	electrode	GG01,	-
3	100007	piezoelectric igniter	GG02,	183306
4	102219	thermocouple, 450mm	GG21	183113

## Ovens (gas)



Item	Order	Description	Model	OEM
1	105878	burner	G_B,	64049130, 48091030
2	100059	pilot burner	GG_B	183305
3	102223	thermocouple		183102

## Ovens (electric)




Item	Order	Description	Model	OEM
1	415585	2000W/400V	E_B,	180352
2	375038	thermostat, 300 C	G_EB	183305




Item	Order	Description	Model	OEM
1	110191	knob		190210
2	110520	symbol	E_B,	190234
3	359169	signal lamp, 400V	G_EB	-
4	359198	signal lamp, 400V		-

## Bains-marie (electric)




Item	Order	Description	Model	OEM
1	375143	thermostat, 110 C	E_WS,	180705
2	110191	knob	E_B/WS,	190210
3	110517	symbol	G_EWS, EWAS_	




Item	Order	Description	Model	OEM
1	415583	1100W/400V		180355
2	375143	thermostat	EWAS_BI	180705

## Tilting bratt pans (electric)




Item	Order	Description	Model	OEM
1	415584	5000W/400V	EKB_	180373
2	375038	thermostat		180706



Item	Order	Description	Model	OEM
1	110191	knob		190210
2	110520	symbol		190234
3	359169	signal lamp, 400V	EKB_	-
4	359198	signal lamp, 400V		-

# Modular ranges


## Boiling pans (electric)



Item	Order	Description	Model	OEM
1	415581	3000W/230V	ESK	180361
2	415582	5000W/230V	EWBK	180362
3	418265	500W/230V	ESK, EBWK	180711



Item	Order	Description	Model	OEM
1	540136	drain tap, 1 1/4"		185001
1	540137	drain tap, 1 1/2"		185000
2	540079	filling funnel	ESK, EBWK	185060
3	541407	pressure relief valve		185053
4	514353	safety valve		185021



Item	Order	Description	Model	OEM
1	375157	safety thermostat		180710
2	541377	pressure switch	ESK, EBWK	185070
3	346438	switch I (complete)		180655
4	346439	switch II (complete)		180656

## Single devices

### Stockpot stoves (gas)



Item	Order	Description	Model	OEM
1	n. l. a.	gas tap EGA		183011
2	101622	gas tap PEL	GHK	183011
3	110191	knob		190210
4	110504	symbol		190231

### Stockpot stoves (electrical)



Pos.	Order	Description	Model	OEM
1	490106	5000W/400V, 400mm	EHK	180411



Item	Order	Description	Model	OEM
1	300023	4-position switch		180510
2	110191	knob	EHK	190210
3	110507	symbol		190220



Item	Order	Description	Model	OEM
1	100059	pilot burner		183305
2	100703	electrode	GHK	-
3	102219	thermocouple, 450mm		183113



**GASTROPARTS.COM**



© 2020 Gastroparts Sp. J. All rights reserved.