



**GASTROPARTS**

# Coldmaster

**[EN]** Cooking

**[DE]** Kochtechnik

**[ES]** Cocción

**[FR]** Cuisson

**[IT]** Cottura

**[PL]** Obróbka termiczna

**[RU]** Термическая обработка

✉ [gastroparts@gastroparts.com](mailto:gastroparts@gastroparts.com)


☎ tel. +48 56 657 00 66

📘 [fb.com/gastroparts.global](https://fb.com/gastroparts.global)


**GASTROPARTS.COM**




## Hot plates/gastroservice dry




Item	Order	Description	Model	OEM
1	359621	lamp	Vista	D9601
2	359663	lamp holder		D9501
3	301029	switch		A0403




Item	Order	Description	Model	OEM
1	379207	controller		A0716
2	379052	sensor	Chef Dry 2,	D7601
3	301003	switch	Chef Dry 3	A0305
4	346321	switch (light)		A0304




Item	Order	Description	Model	OEM
1	379207	controller	Vista, Base, Dry	A0716
2	379052	sensor		D7601
3	301003	switch	Base, Dry	A0305



Item	Order	Description	Model	OEM
1	550844	cover		0064802
2	550845	lamp holder	Chef Bay 2,	0054804
3	550846	lamp holder	Chef Bay 3	0054805
4	550847	cover		0064801




Item	Order	Description	Model	OEM
1	418012	heating element, 400W	Vista,	3154802
2	418013	heating element, 825W	Dry 1000/1200,	3014801
3	418014	heating element, 950W	Dry 1400/1600	3024801



Item	Order	Description	Model	OEM
1	359371	lamp, 18W	Chef Dry 2	B6302
2	359372	lamp, 30W	Chef Dry 3	B6303
3	401141	ballast	Chef Dry 2	A6803
4	401142	ballast	Chef Dry 3	A6802

## Hot bars



Item	Order	Description	Model	OEM
1	418015	heating element	Chef Dry 2,	3914801
2	601147	fan	Chef Dry 3	D0702



Item	Order	Description	Model	OEM
1	693328	handle	Chef Dry 2,	D0102
2	700425	spring	Chef Dry 3	A2502

Suitable for Coldmaster

**GASTROPARTS.COM**



© 2020 Gastroparts Sp. J. All rights reserved.