



GASTROPARTS

Thielmann

[EN] Cooking

[DE] Kochtechnik

[ES] Cocción

[FR] Cuisson

[IT] Cottura

[PL] Obróbka termiczna

[RU] Термическая обработка

✉ gastroparts@gastroparts.com

☎ tel. +48 56 657 00 66

📘 fb.com/gastroparts.global

GASTROPARTS.COM



Open tops (gas)



Item	Order	Description	Model	OEM
1	105873	burner cover C		540486, 144340
1	105874	burner cover D/E	HG2/4/6, HGB4/6, HGBE4/6	540487, 144341
2	105871	burner C		193466
2	105870	burner D		193467
2	105869	burner E		193468




Item	Order	Description	Model	OEM
1	101095	gas tap	HG2/4/6,	144424
2	111832	knob	HGB4/6,	540448
3	111835	symbol	HGBE4/6	540449

Open tops (electric)



Item	Order	Description	Model	OEM
1	490088	2500W/400V		144170
1	490090	4000W/400V	HE2/4/6,	144171
2	359027	signal lamp/green	HEB4/6/6W	143841
3	359048	signal lamp/yellow		540180



Item	Order	Description	Model	OEM
1	300106	7-position switch		141187
2	111831	knob	HE2/4/6,	144104, 540422
3	111838	symbol	HEB4/6/6W	144107, 540477

Open tops (solid top/gas)





Item	Order	Description	Model	OEM
1	105875	burner		144818
2	101095	gas tap	HGG4,	144424
3	111832	knob	HGGB4	540448
4	111835	symbol		540449




Item	Order	Description	Model	OEM
1	100061	pilot burner		140928
2	102219	thermocouple	HGG4,	136030
3	100704	electrode	HGGB4	-


Ovens (electric)



Item	Order	Description	Model	OEM
1	418223	2000 W/400 V		540471, 144168
1	418222	2800 W/400 V	HGBE4/6, HEB4/6/W6	540831, 144169
2	375695	safety thermostat		540470, 251116



Item	Order	Description	Model	OEM.
1	300190	switch		141924, 540472
2	111831	knob	HGBE4/6, HEB4/6/W6	540422, 144104
3	111833	symbol		540469, 144108



Item	Order	Description	Model	OEM
1	375038	thermostat		139783
2	111831	knob		144104, 540422
3	111834	symbol	HGBE4/6, HEB4/6/W6	144109, 540457
4	359027	signal lamp/green		143841
5	359048	signal lamp/yellow		540180

Ovens (mechanical)



Item	Order	Description	Model	OEM
1	700600	spring/left	HGB4/6, HGBE4/6, HEB4/6/W6	540453, 150095
2	700601	spring/right		141039, 540454



Item	Order	Description	Model	OEM
1	100008	piezoelectric igniter	HGG4,	144333
2	100017	ignition cable	HGGB4	-

Ovens (gas)


no picture!



Item	Order	Description	Model	OEM.
1	105876	burner		193660
2	101900	thermostat	HGB4/6,	144428
3	111832	knob	HGGB4	540448
4	111839	symbol		540456




Item	Order	Description	Model	OEM
1	102831	pilot burner	HGB4/6, HGGB4	540450, 144400
2	102076	thermocouple, 850mm		144404



Item	Order	Description	Model	OEM
1	100008	piezoelectric igniter	HGB4/6,	144333
2	100701	electrode	HGGB4	-


Bains-marie (electric)



Item	Order	Description	Model	OEM
1	415760	1800W/230V		540463, 144167
2	520323	gasket	WE2/1-3/1, WEW2/1-3/1	144334
3	520324	flange		144343



Item	Order	Description	Model	OEM
1	375019	thermostat		144180
2	111831	knob	WE2/1-3/1, WEW2/1-3/1	144104
3	111840	symbol		144108



Item	Order	Description	Model	OEM
1	300001	switch		540461, 142752
2	359027	signal lamp/green	WE2/1-3/1, WEW2/1-3/1	143841
3	359048	signal lamp/yellow		540180

Fry tops (gas)



no picture!

Item	Order	Description	Model	OEM
1	105877	burner		193635
2	101095	gas tap	BGG,	144424
3	111832	knob	BGR	540448
4	111835	symbol		540449




Item	Order	Description	Model	OEM
1	102831	pilot burner		540450, 144400
2	100701	electrode	BGG, BGR	-
3	102219	thermocouple, 450mm		136030




Item	Order	Description	Model	OEM
1	100008	piezoelectric igniter	BGG, BGR	144333
2	100018	ignition cable		-

Fry tops (electric)




Item	Order	Description	Model	OEM
1	418238	2000W/400V		540458, 143831
2	375706	safety thermostat	BEG, BEG-R, BER, BEG-C	540406, 144095
3	300001	switch		540461, 142752




Item	Order	Description	Model	OEM
1	375038	thermostat		139783
2	111831	knob		540422, 144104
3	111834	symbol	BEG, BEG-R, BER, BEG-C	540457, 144109
4	359027	signal lamp/green		143841
5	359048	signal lamp/yellow		540180

Suitable for Thielmann


Fryers



Item	Order	Description	Model	OEM
1	418263	7200W/230V		540441, 144187
2	375707	safety thermostat	FE2x8, FE16	540443, 144182
3	345060	micro switch		141907



Item	Order	Description	Model	Vergleichs-Nr.
1	375708	thermostat		540444, 143766
2	111831	knob	FE2x8, FE16	540422, 144104
3	111869	symbol		541138



Item	Order	Description	Model	OEM
1	300193	switch		540445, 143765
2	111831	knob	FE2x8, FE16	510422, 144104
3	111870	symbol		



Item	Order	Description	Model	OEM
1	345060	micro switch		141907
2	346426	push button	FE2x8,	130406
3	359027	signal lamp/green	FE16	143841
4	359048	signal lamp/yellow		540180




Pos.	Order	Description	Model	OEM
1	970448	fryer basket	FE2x8, FE16	540446, 143772

Tilting bratt pans (gas)

no picture! no picture! no picture!
1 2 3

Item	Order	Description	Model	OEM
1	105917	burner/complete	PG2/1	144615
2	105919	burner/right	PG3/1	144558
3	105918	burner/left		144557




Item	Order	Description	Model	OEM
1	106027	gas thermostat		540403, 144561
2	111832	knob	PG2/1, PG3/1	544448
3	111839	symbol		544456



Item	Order	Description	Model	OEM
1	102831	pilot burner		540450, 144400
2	100701	electrode	PG2/1,	-
3	100008	piezoelectric igniter	PG3/1	144333
4	102076	thermocouple		144404

Tilting bratt pans (electric)




Item	Order	Description	Model	OEM
1	415594	2565 W/400V	PE2/1, PE3/1,	182329, 143648
2	375706	safety thermostat	PE2/1M, PE3/1M	540406, 144095
3	380213	contactor		144764, 143815

Tilting bratt pans (motor drive)



Item	Order	Description	Model	OEM
1	345707	contactor block		143052
2	346271	push button	PE2/1M, PE3/1M	144412
3	346435	symbol		144415


Boiling pans (gas)



Item	Order	Description	Model	OEM
1	300001	switch		142752, 540461
2	375038	thermostat	PE2/1, PE3/1,	139783
3	111831	knob	PE2/1M, PE3/1M	144104, 540422
4	111834	symbol		144109, 540457



Item	Order	Description	Model	OEM
1	105905	burner	universal	541545, 141960
2	101166	ignition control module		540409, 144750



Item	Order	Description	Model	OEM
1	100062	pilot burner	universal	130132
2	100085	pilot burner	KG100WA	140928

Boiling pans (electric)



Item	Order	Description	Model	OEM
1	415604	3000W/3 phases 230V	KE150	541218, 143833
2	418286	6000W/3 phases 230V	KE40, KE60	540821, 143834
3	418270	9000W/3 phases 230V	KE80-150, KE60K-150K	540717, 143836

Tilting bratt pans (mechanical)




Item	Order	Description	Model	OEM
1	690901	hand wheel	universal	540403, 144139
2	700513	gas pressure spring	2/1	540478, 144662
3	700515	gas pressure spring	3/1	541124, 144661



Pos.	Order	Description	Model	OEM
1	693447	cover rotating joint	universal	144138


Suitable for Thielmann



Item	Order	Description	Model	OEM
1	415405	6000W/3 phases 230V	KER150-400	144346
2	418287	9000W/3 phases 230V	KER100-400	144347
3	415653	600W/230V	universal	143895




Item	Order	Description	Model	OEM
1	300104	4-position switch	KE_	141188
2	111831	knob	KE_K,	144104
3	111895	symbol (4-tacts)	KER_	540432



Item	Order	Description	Model	OEM
1	380213	contactor	KE_, KE_K, KER_	144764
2	380261	contactor	KER150-400	130274
3	380265	contactor	KER250-400	144345



Item	Order	Description	Model	OEM
1	300074	switch (0-I)		144696
2	111831	knob	KG	141188
3	111896	symbol (0-I-0-I)		-




Item	Order	Description	Model	OEM
1	541408	pressure switch		540416, 143896
2	375519	safety thermostat	universal	540414, 143830
3	380036	energy regulator		538255, 221406




Item	Order	Description	Model	OEM
1	345707	contactor block		143052
2	346271	push button	KG	144412
3	346435	key plate		144411

Boiling pans (mechanical)



Item	Order	Description	Model	OEM
1	111831	knob		144104
2	111894	symbol (1-10)		540826
3	359027	signal lamp/green	universal	143841
4	359048	signal lamp/yellow		540180
5	359026	signal lamp/red		540181




Item	Order	Description	Model	OEM
1	693450	cover rotating joint	KE_K, KE40-150, KG80-100	144122
1	693449	cover rotating joint	KG40-60	144701
2	693448	cover rotating joint	KER_	144466



Item	Order	Description	Model	OEM
1	514355	mixing valve		540830, 144132
2	514332	rotating arm	universal	144407
3	514272	steam trap		540408, 144742



Item	Order	Description	Model	OEM
1	514356	handle		151905
2	514358	push button/blue	universal	151904
3	514359	push button/red		151903



Item	Order	Description	Model	OEM
1	540137	drain cock 1 1/2"	KE_, KG_	130176
2	540138	drain cock, 2"	KER_	130177



Item	Order	Description	Model	OEM
1	514354	safety valve	universal	144749
2	541398	manometer		144192

Boiling pans (motor drive)



Item	Order	Description	Model	OEM
1	345060	micro switch, NO	KE_K	141907
2	345061	micro switch, NC		144412



Item	Order	Description	Model	OEM
1	345707	contactor block		143052
2	346271	push button	KE_K	144412
3	346435	key plate		144415



GASTROPARTS.COM



© 2020 Gastroparts Sp. J. All rights reserved.