



GASTROPARTS

Universal Catalogue › Electric Components ›

[EN] **Magnetrons**

[DE] Magnetrons

[ES] Magnetrones

[FR] Magnétrons

[IT] Magnetron

[PL] Magnetrony

[RU] Магнитроны


✉ gastroparts@gastroparts.com

☎ tel. +48 56 657 00 66

📘 fb.com/gastroparts.global

GASTROPARTS.COM





magnetrons

14

ACP.	476
Amana.	476
Cookmax.	476
Galanz.	476
Horeca-Select.	476
Merrychef.	476
Panasonic.	476
Sharp.	476
Sirman.	477
TurboChef.	477



magnetrons

ACP



fig.	Part No.	type	Ref. No.
1	403363	2M246-35GKH	53002025
2	403361	2M248H(A)-B	59004010
2	403371	2M248H(A)-LT	56002014
3	403364	2M248J	53002004
3	403360	2M355J(A)	59004083



fig.	Part No.	type	Ref. No.
4	403359	2M248K(A)	59004013
5	403362	2M262A-01BA	59002081
6	403546	2M303H(YL)	54137088

Amana



fig.	Part No.	type	Ref. No.
1	403361	2M248H(A)-B	59001484

Cookmax



fig.	Part No.	type	Ref. No.
1	402121	2M240H(L2)	RV-MZA299WRE0
1	402119	2M281H(L)	RV-MZA335WRZZ
1	402120	2M282H(L)	RV-MZA322WREZ

Galanz



fig.	Part No.	type	Ref. No.
1	403173	2M248J(JT)	GMW1025-C08
2	403259	M24FB-610A	GMW1030-C08

Horeca-Select




fig.	Part No.	type	Ref. No.
1	403173	2M248J(JT)	GMW1025-C08
2	403259	M24FB-610A	GMW1030-C08

Merrychef



fig.	Part No.	type	Ref. No.
1	403381	2M248H(ME)	30Z1349

Panasonic



fig.	Part No.	type	Ref. No.
1	403567	2M210-M1E-NF	2M210-M1E-NF

Sharp




fig.	Part No.	type	Ref. No.
1	402121	2M240H(L2)	RV-MZA299WRE0
1	402119	2M281H(L)	RV-MZA335WRZZ
1	402120	2M282H(L)	RV-MZA322WREZ

Sirman

			
fig.	Part No.	type	Ref. No.
1	402123	2M210M1	P2M210-M1GL
2	402845	2M244-M23	2M244M23


TurboChef


			
fig.	Part No.	type	Ref. No.
1	402053		100861
2	403321	2M248J(FD)	NGC-3015



GASTROPARTS

GASTROPARTS Sp. J.
Klonowica 37
87-100 Toruń


www.gastroparts.com 

gastroparts@gastroparts.com 

tel. +48 56 657 00 68 

[/gastroparts.global](#) 

[/gastroparts.global](#) 



magnetrons

14

ACP.	476
Amana.	476
Cookmax.	476
Galanz.	476
Horeca-Select.	476
Merrychef.	476
Panasonic.	476
Sharp.	476
Sirman.	477
TurboChef.	477



magnetrons

ACP



fig.	Part No.	type	Ref. No.
1	403363	2M246-35GKH	53002025
2	403361	2M248H(A)-B	59004010
2	403371	2M248H(A)-LT	56002014
3	403364	2M248J	53002004
3	403360	2M355J(A)	59004083



fig.	Part No.	type	Ref. No.
4	403359	2M248K(A)	59004013
5	403362	2M262A-01BA	59002081
6	403546	2M303H(YL)	54137088

Amana



fig.	Part No.	type	Ref. No.
1	403361	2M248H(A)-B	59001484

Cookmax



fig.	Part No.	type	Ref. No.
1	402121	2M240H(L2)	RV-MZA299WRE0
1	402119	2M281H(L)	RV-MZA335WRZZ
1	402120	2M282H(L)	RV-MZA322WREZ

Galanz



fig.	Part No.	type	Ref. No.
1	403173	2M248J(JT)	GMW1025-C08
2	403259	M24FB-610A	GMW1030-C08

Horeca-Select




fig.	Part No.	type	Ref. No.
1	403173	2M248J(JT)	GMW1025-C08
2	403259	M24FB-610A	GMW1030-C08

Merrychef



fig.	Part No.	type	Ref. No.
1	403381	2M248H(ME)	30Z1349

Panasonic



fig.	Part No.	type	Ref. No.
1	403567	2M210-M1E-NF	2M210-M1E-NF

Sharp



fig.	Part No.	type	Ref. No.
1	402121	2M240H(L2)	RV-MZA299WRE0
1	402119	2M281H(L)	RV-MZA335WRZZ
1	402120	2M282H(L)	RV-MZA322WREZ

Sirman



fig.	Part No.	type	Ref. No.
1	402123	2M210M1	P2M210-M1GL
2	402845	2M244-M23	2M244M23

TurboChef





fig.	Part No.	type	Ref. No.
1	402053		100861
2	403321	2M248J(FD)	NGC-3015

GASTROPARTS.COM



© 2020 Gastroparts Sp. J. All rights reserved.